

# **NK260 Integrated CNC System**

**Manufacturers' Manual**

---

12th Edition

Weihong Electronic Technology Co., Ltd.

The copyright of this manual belongs to Weihong Electronic Technology Co., Ltd. (hereinafter referred to as Weihong Company). This manual and any image, table, data or other information contained in this manual may not be reproduced, transferred, or translated without any prior written permission of Weihong Company.

The information contained in this manual is constantly being updated. You can login to the official website of Weihong Company [www.en.weihong.com.cn](http://www.en.weihong.com.cn) to download the latest PDF edition for free.

# Preface

## About This manual

This manual is intended for manufacturers. If you use Weihong CNC system for the first time, it is suggested to read through this manual. If not, however, you can search for the desired information via the contents.

With 7 chapters, this manual can be divided into 5 parts, as follows:

- 1) Precautions part. This part mainly lists the notices of storage and transportation, installation and wiring, usage and so on. You should read them carefully to ensure safe operation.
- 2) Hardware part, including chapter 1, 2 and 5. Chapter 1 and 2 mainly talk about product configuration and hardware introduction of NK260. While chapter 5 refers to driver parameters and terminal board wiring diagrams of different brands.
- 3) Software operation part. Chapter 3 introduces software interfaces and operation corresponding to each function and lists related parameters and setting notes. After reading through this part, you can learn the operation menus and commands.
- 4) Maintenance part. Chapter 4 talks about maintenance information so that you can take corresponding steps in case of breakdown.
- 5) Appendix part, including chapter 6 and 7. Chapter 6 lists all the parameters while chapter 7 contains the software license agreement.

## Applicable Product Model

This manual is applicable to NK260 integrated CNC system. Refer to the table below for details.

Product Model	Remarks
NK260 integrated CNC system	Abbreviated as NK260; system in this manual refers to NK260 integrated CNC system, if there is no particular explanation.

## Contact Us

You can contact us by the following info for technical support and pre-sales / after-sales service:

Company Name: Weihong Electronic Technology Co., Ltd.  
 Headquarters Address: No.1590, Huhang Rd., Fengxian, Shanghai, PRC 201400  
 Tel: +86-21-33587550  
 Fax: +86-21-33587519  
 Website: <http://en.weihong.com.cn>

## Revision History

You can refer to the following table for the revision records of each edition.

Date	Edition	Revision
2016.02	R12	1) Contact information updated; 2) Wiring diagrams of drivers are updated in section 5.2 and 5.3; 3) Fig. 3-1, Fig. 3-4, Fig. 3-9, Fig. 3-38, Fig. 3-78 and Fig. 3-79 updated. 4) Section 3.11.1 and 3.11.2 updated. 5) Styles updated; 6) Other revisions.
2015.08	R10	Mainly including: 1) Introduction to extended WCSs (G154~G173) is added in section 3.7.2, and software interfaces of WCSs setting is added in section 3.7.3; 2) Update tool compensation knowledge in section 3.11.2; 3) On the basis of the latest system, update operating system maintenance operations in section 4.1, where descriptions about system “Eboot” interface in section 4.1.3 and presentation of software update interface in section 4.1.4 are added; 4) Update parameters information according to the latest version of software; 5) Other revisions.
2015.03	R9	Mainly including: 1) Section 3.2.2 further introduces the calculation and setting of pulse equivalent with different motor systems; 2) Section 3.11.2 carries out a more detailed introduction to tool compensation; 3) Section 4.3 reschedules the common trouble shooting; 4) Section 5 adds driver parameters and wiring diagram of WISE servo driver and MITSUBISHI MR-JE servo driver.

## Precautions

Precautions can be divided into caution and warning according to the degree of possible loss or injury in case of negligence or omission of precautions stipulated in this manual.



: general info, mainly for informing, such as supplementary instructions and conditions to enable a function. In case of negligence or omission of this kind of precautions, you may not activate a function. Note that in some circumstances, negligence or omission of this kind of precautions could cause physical injury or machine damage.



: warning info requiring special attention. In case of negligence or omission of this kind of precautions, you may suffer physical injury, or even death, machine damage or other losses.



### 1) Precautions Related to Storage and Transportation

- The products should be transported properly in terms of the weight;
- An excess of specified quantity of stacking products is prohibited;
- Climbing, standing or placing heavy loads on the products is prohibited;
- Dragging or carrying the products via cables or devices connected to them is prohibited;

### 2) Precautions Related to Installation

- Only when this equipment installed in the qualified electricity cabinet can it be used. The construction of the cabinet must reach IP54 grade of protection;
- Paste sealing strips on the joint of the cabinet to seal all the cracks;
- Cable entry should be sealed while easy-to-open on the spot;
- A fan or heat exchanger should be adopted for the heat dissipation and air convection of the cabinet;
- If a fan is adopted, air strainer is a must in air inlet or air outlet;
- Dust or cutting fluids may have access to the CNC device via the tiny cracks and tuyere. Therefore it is necessary to pay attention to the surroundings and air flow direction of the air vent to make sure that the outflow gas is towards pollution source;
- 100 mm space should be preserved between the back of the CNC device and the cabinet wall for plugging cable connected with the device and the ventilation & heat dissipation in the cabinet;
- Space between this device and other equipments should also be preserved according to the requirements;
- The product should be installed firmly and without vibration. During installing, casting, knocking, striking, or loading on the product is forbidden;
- To reduce electromagnetic interference, power-supply components used should be above AC or DC 50V and the space between cable and CNC device should be preserved above 100mm;
- It will be better if CNC device is installed at a position facilitating debugging and maintenance.

 **WARNING****3) Precautions Related to Wiring**

- Only qualified people are allowed to participate in the wiring and checking;
- The CNC device should be grounded reliably and grounding resistance should be less than 4 ohm. Neutral line is absolutely not allowed to replace earth wire. Otherwise, it may result in malfunction of the device due to the interference;
- Wiring should be firm and steady, or misoperation may occur;
- Voltage values and positive & negative polarity of any connection plug should be in accordance with specifications set forth in the manual, or it may result in breakdowns such as short circuit and permanent damage to the device;
- To guard against electric shock or CNC device damage, fingers should keep dry before plugging or touching switch;
- The connecting wire should not be damaged and squeezed, or the leakage or short circuit may occur;
- It is prohibited to plug or open the chassis of CNC device when power on.

**4) Precautions Related to Running & Debugging**

- Parameters setting should be checked before running, since wrong setting may lead to accidental movements;
- Modification to parameters should be within the allowable range, or such breakdowns as unsteady running and machine damage will occur.

**5) Precautions in Use**

- Before power-on, please make sure that the switch is on blackout to avoid occasional start-up;
- Please check the electromagnetic compatibility during electrical design in order to avoid or reduce electromagnetic interference to the CNC device. A low pass filter should be employed to reduce electromagnetic interference if there are other electrical devices nearby;
- It is not allowed to frequently power on and power off. It is recommended to power up the machine again at least one (1) minute later after power failure or blackout.

 **CAUTION****1) Precautions Related to Product and Manual**

 **CAUTION**

- Matters related to restrictions and functions available stipulated in the manuals issued by the machine manufacturer are prior to those in this manual;
- This manual assumes all the optional functions are available, which you must confirm through manuals issued by the machine manufacturer;
- Please refer to manuals issued by the machine manufacturer for the instructions of machine tools;
- Functions, and software interfaces vary with the system and the version of software. Before using the system, you must confirm the specifications.

**2) Precautions When Opening the Package**

- Please make sure that the products are what you have ordered;
- Check if the products are damaged in transit;
- Check if the components and accessories are damaged or missing in terms of the detailed list;
- Please contact us promptly if product discrepancy, accessory missing or transit damage occurs.





# Contents

<b>1</b>	<b>Overview .....</b>	<b>7</b>
1.1	System Configuration.....	8
1.2	An Introduction to Hardware.....	8
1.2.1	Structure Specification.....	8
1.2.2	Connection Schematic Diagram.....	11
<b>2</b>	<b>Wiring.....</b>	<b>12</b>
2.1	Basic Concepts of Signal.....	13
2.1.1	Signal Types.....	13
2.1.2	Binary Input .....	14
2.1.3	Binary Output .....	15
2.2	Wiring Specification of Terminal Board.....	16
2.2.1	Wiring Diagram of Terminal Board .....	17
2.2.2	Port Specification of Terminal Board .....	18
2.3	Port Definition and Wiring Specification.....	21
2.3.1	Driver Interface Definition .....	21
2.3.2	Handwheel Interface Definition.....	22
<b>3</b>	<b>Operation.....</b>	<b>23</b>
3.1	Debugging Steps .....	26
3.2	Adjustment of Axial Direction and Pulse Equivalent .....	27
3.2.1	Axial Direction Adjustment .....	27
3.2.2	Pulse Equivalent Adjustment .....	28
3.2.3	Upper & Lower Limit Setting of Workbench Stroke .....	30
3.3	Returning to Machine Origin.....	31
3.3.1	Principle of Motion of Returning to Machine Origin .....	32
3.3.2	Parameters Specifications.....	34
3.3.3	FAQ & Troubleshooting .....	36
3.4	Spindle Parameters Adjustment .....	38

<b>3.5</b>	<b>Port Polarity Adjustment .....</b>	<b>40</b>
<b>3.6</b>	<b>Tool Measurement.....</b>	<b>42</b>
3.6.1	Software Interface .....	43
3.6.2	Mobile Calibration .....	43
3.6.3	Fixed Calibration .....	44
3.6.4	First Calibration/ Tool Calibration after Tool Change .....	45
<b>3.7</b>	<b>Offset Setting.....</b>	<b>47</b>
3.7.1	WCS (Workpiece Coordinate System) .....	47
3.7.2	Extended WCS.....	48
3.7.3	Software Interface .....	49
<b>3.8</b>	<b>Centering .....</b>	<b>50</b>
3.8.1	Two-point Centering .....	50
3.8.2	Circle Centering.....	51
<b>3.9</b>	<b>Adjustment of Velocity &amp; Acceleration .....</b>	<b>52</b>
3.9.1	Feedrate Setting.....	52
3.9.2	Traverse Speed Setting.....	52
3.9.3	Parameters Specification .....	53
<b>3.10</b>	<b>Simulation &amp; Track.....</b>	<b>56</b>
3.10.1	Simulation.....	56
3.10.2	Motion Trace.....	57
<b>3.11</b>	<b>Compensation .....</b>	<b>58</b>
3.11.1	Screw Error Compensation .....	58
3.11.2	Tool Compensation .....	62
3.11.3	Across Quadrant Error (AQE) Compensation .....	66
<b>3.12</b>	<b>Log and Diagnosis .....</b>	<b>67</b>
3.12.1	Log .....	67
<b>3.13</b>	<b>Program File Management .....</b>	<b>68</b>
3.13.1	Program Wizard.....	68
3.13.2	Part Statistic.....	69
3.13.3	Program File .....	70
<b>3.14</b>	<b>Handwheel Operation.....</b>	<b>76</b>
3.14.1	Handwheel Mode .....	76

3.14.2	Handwheel Guide .....	78
<b>3.15</b>	<b>System Management .....</b>	<b>78</b>
3.15.1	System Info .....	78
3.15.2	Network Connection.....	79
3.15.3	Language.....	79
3.15.4	Register .....	79
<b>3.16</b>	<b>Network Connection and Share .....</b>	<b>80</b>
3.16.1	IP Setup.....	80
3.16.1.1	Direct Connection or Switch Connection .....	80
3.16.1.2	Router Connection .....	83
3.16.1.3	Multiple NK260 Connection .....	84
3.16.2	Connection Verification Setup .....	85
3.16.3	NK260 Network Files Management by PC via FTP.....	85
3.16.4	NK260 Network Files Management by PC via Network Sharing.....	86
<b>3.17</b>	<b>Auxiliary Function.....</b>	<b>87</b>
3.17.1	Start Line (Selective Processing) .....	87
3.17.2	Breakpoint Resume.....	88
3.17.3	Parameter Auto Backup.....	88
3.17.4	User Code Input .....	88
3.17.5	Coordinate Backup .....	89
<b>3.18</b>	<b>Tool Magazine.....</b>	<b>90</b>
3.18.1	Auto Tool Change of Linear Tool Magazine .....	90
3.18.2	Auto Tool Change of Circular Tool Magazine .....	92
3.18.3	Related Parameters.....	93
<b>4</b>	<b>Maintenance .....</b>	<b>95</b>
<b>4.1</b>	<b>Operating System Maintenance .....</b>	<b>96</b>
4.1.1	Software Update .....	96
4.1.2	Mirror Image Update .....	98
4.1.3	System “Eboot” Interface .....	98
4.1.4	System Update Interface.....	100
<b>4.2</b>	<b>Warning Information .....</b>	<b>101</b>
<b>4.3</b>	<b>Common Troubleshooting .....</b>	<b>103</b>
4.3.1	What should you do if the spindle does not rotate? .....	103

4.3.2	What should you do if an axis does not move? .....	103
4.3.3	What should you do if servo motor Z brake can't be opened? .....	103
4.3.4	What should you do if machine tool returns to the machine origin abnormally? .....	104
4.3.5	What should you do if the machine tool motions upward after arriving at the position of tool presetter during calibration? .....	104
<b>5</b>	<b>Driver .....</b>	<b>105</b>
<b>5.1</b>	<b>Driver Parameters .....</b>	<b>107</b>
5.1.1	Parameter Setting of WISE Servo Driver .....	107
5.1.2	Parameter Setting of YASKAWA $\Sigma$ -II Servo Driver .....	108
5.1.3	Parameter Setting of YASKAWA $\Sigma$ -V/ $\Sigma$ -7 Servo Driver .....	110
5.1.4	Parameter Setting of PANASONIC MINAS A4 Servo Driver .....	111
5.1.5	Parameter Setting of PANASONIC MINAS A5 Servo Driver .....	111
5.1.6	Parameter Setting of MITSUBISHI MR-JE Servo Driver .....	113
5.1.7	Parameter Setting of MITSUBISHI MR-E Servo Driver .....	114
5.1.8	Parameter Setting of DELTA ASDA-A Servo Driver .....	115
5.1.9	Parameter Setting of DELTA ASDA-B Servo Driver .....	116
5.1.10	Parameter Setting of DELTA ASDA-A2 Servo Driver .....	118
5.1.11	Parameter Setting of DELTA ASDA-B2 Servo Driver .....	119
5.1.12	Parameter Setting of SANYO PY Servo Driver .....	121
5.1.13	Parameter Setting of SANYO R Servo Driver .....	123
5.1.14	Parameter Setting of SANYO Q Servo Driver .....	123
5.1.15	Parameter Setting of KT270 Servo Driver .....	124
5.1.16	Parameter Setting of FUJI FALDIC- $\beta$ Servo Driver .....	126
5.1.17	Parameter Setting of STONE GS Servo Driver .....	127
5.1.18	Parameter Setting of TECO TSDA Servo Driver .....	128
<b>5.2</b>	<b>Wiring Diagram of NK260 Host and Differential Input Stepping Driver .....</b>	<b>130</b>
<b>5.3</b>	<b>Wiring Diagram of Driver and Terminal Board .....</b>	<b>130</b>
5.3.1	Wiring Diagram of WISE Servo Driver .....	131
5.3.2	Wiring Diagram of YASKAWA AC Servo Driver .....	132
5.3.3	Wiring Diagram of PANASONIC AC Servo Driver .....	133
5.3.4	Wiring Diagram of MITSUBISHI MR-JE Servo Driver .....	134
5.3.5	Wiring Diagram of MITSUBISHI MR-E Servo Driver .....	135
5.3.6	Wiring Diagram of DELTA Servo Driver .....	135

5.3.7	Wiring Diagram of FUJI Servo Driver .....	138
5.3.8	Wiring Diagram of HITACHI Servo Driver .....	138
5.3.9	Wiring Diagram of SANYO PY Servo Driver .....	139
5.3.10	Wiring Diagram of SANYO R Servo Driver.....	140
5.3.11	Wiring Diagram of KT270 Servo Driver .....	140
5.3.12	Wiring Diagram of STONE GS Servo Driver .....	141
5.3.13	Wiring Diagram of TECO TSDA Servo Driver .....	142
5.3.14	Wiring Diagram of TECO ESDA Servo Driver .....	143
<b>6</b>	<b>Parameter Overview.....</b>	<b>144</b>
<b>7</b>	<b>Software License Agreement .....</b>	<b>152</b>



# 1 Overview

---

- 1.1 System Configuration ..... 8
- 1.2 An Introduction to Hardware ..... 8
  - 1.2.1 Structure Specification ..... 8
  - 1.2.2 Connection Schematic Diagram ..... 11

# 1.1 System Configuration

NK260 integrated system consists of the following components:

- One host of NK260
- One EX9A4 terminal board
- One DB9M/F cable (5m)
- Servo cable (brand, length and quantity decided by customers)
- NK-MPG-06 Handwheel (optional)

# 1.2 An Introduction to Hardware

## 1.2.1 Structure Specification

### ◆ A Picture of NK260



Fig. 1-1 A Picture of NK260

### ◆ Mounting Dimension

After NK260 is installed on the machine tool, 100 mm space should be preserved in its surrounding for wiring convenience and for ensuring ventilation in the cabinet. And the mounting dimension is shown in Fig. 1-2.






Fig. 1-2 Mounting Dimension of NK260 Integrated System

◆ Front View of NK260




Fig. 1-3 Front View of NK260

◆ Rear View of NK260




Fig. 1-4 Rear View of NK260

### 1.2.2 Connection Schematic Diagram




Fig. 1-5 Connection Schematic Diagram

# 2 Wiring

---

<b>2.1</b>	<b>Basic Concepts of Signal .....</b>	<b>13</b>
2.1.1	Signal Types.....	13
2.1.2	Binary Input.....	14
2.1.3	Binary Output.....	15
<b>2.2</b>	<b>Wiring Specification of Terminal Board .....</b>	<b>16</b>
2.2.1	Wiring Diagram of Terminal Board.....	17
2.2.2	Port Specification of Terminal Board.....	18
<b>2.3</b>	<b>Port Definition and Wiring Specification .....</b>	<b>21</b>
2.3.1	Driver Interface Definition .....	21
2.3.2	Handwheel Interface Definition .....	22

## 2.1 Basic Concepts of Signal

### 2.1.1 Signal Types

The signal types of NK260 system can be divided into the following 4 types: binary input signal, relay output signal, differential output signal and analog output signal.

#### ◆ Binary Input Signal

Binary input signal is active low and supports NO and NC input signals (through modifying input port polarity in the software). Conducting to GND (i.e. grounding signal) in NO connection means signal detected, and disconnecting with GND in NC connection means signal detected.



NK260 system also supports high level effective, if this function is needed, please choose the related terminal board EX6A4; at this time, conducting to 24V in NO connection means signal detected, and disconnecting with 24V in NC connection means signal detected.

#### ◆ Relay Output Signal

The relay output contact points on the terminal board have load capacity: 10A/250VAC and 10A/30VDC, which can control 220V AC load of low power. If high power load is needed, a contactor can be used. Please see Fig. 2-1.




Fig. 2-1 Connection of Relay Output and Contactor

#### ◆ Differential Output Signal

Differential signal refers to two equivalent signals with opposite phases sent by driving end, and the voltage difference of these two signals is used for deciding whether the logical status of differential signal is “0” or “1”.

Pulse command format of controlling driver motion is pulse + direction, negative logic. And this signal adopts differential signal transmission mode.

◆ **Analog Output Signal**

SVC is controllable voltage output of 0~10V and externally connected with analog voltage frequency command inputs of inverter. Therefore altering the controllable voltage leads to inverter frequency change and a change of inverter frequency will change the spindle speed.




Fig. 2-2 Electric Circuit of Analog Output Signal

## 2.1.2 Binary Input

◆ **Connection of Binary Input and External Circuit**

The wiring method between binary input signal and a mechanical switch is shown in Fig. 2-3:




Fig. 2-3 Connection of Mechanical Switch and Binary Input

Binary input signal can be connected with a photoelectric switch or a proximity switch of NPN (NO or NC) type. Its joining method is as below. And you can use switch of PNP type by simply adopting the related terminal board EX6A4.




Fig. 2-4 Binary Input of NPN Type Connecting with Photoelectric Switch or Proximity Switch

◆ **Power Requirement**

It is recommended to adopt DC24V/4.5A switch power for relays on the terminal board. If there are a

great many DC 24V relays controlled by binary output signal, you can appropriately expand the power source capacity or add extra power (forcibly sharing ground with external power supply). Z-axis brake and solenoid valve also need DC24V instead of external power to the greatest extent to reduce the interference to CNC device by solenoid valve, etc.

### 2.1.3 Binary Output

#### ◆ Signal Signature

The internal equivalent circuit of binary output is shown in Fig. 2-5.




Fig. 2-5 Equivalent Circuit of Binary Output Interface

#### ◆ Technical Parameter

- 1) Supply voltage: 24VDC
- 2) Binary open-collector output

OC (open-collector) outputs drive capability with maximum allowable operating voltage 30VDC and maximum allowable current 20mADC; so when the output terminal is active low, the maximum allowable sucked current is 20mA.

#### ◆ Connection of Binary Output and External Circuit

The connection of solid-state relay and binary output is shown in Fig. 2-6.




Fig. 2-6 Connection of Solid-state Relay and Binary Output

The connection of binary output and optical coupler is shown in Fig. 2-7.




Fig. 2-7 Connection of Binary Output and Optical Coupler



The max. allowable voltage of optical coupling open collector output is: 30VDC, with max. allowable current 50mA.

## 2.2 Wiring Specification of Terminal Board


EX9A4 is the terminal board for NK260 as standard, and another option is EX26A3, used for I/O ports expansion. Except for one piece of EX9A4, up to five pieces of terminal board EX26A3 can be connected for expanding I/Os by 50/40.

There is a red LED indicator light near each input port on EX9A4, used for indicating whether port wiring is correct in machine tool debugging. The concrete method is: press the switch to give the corresponding port signal. If the LED near this port is on, the wiring is right; if not, check whether the wiring is wrong.

To check whether the port is damaged, open the software and test. For details, refer to section 3.5 section Port Polarity Adjustment.




## 2.2.1 Wiring Diagram of Terminal Board



Note: NO ports are normally open while NC ports normally closed.

Fig. 2-8 Wiring Diagram of Terminal Board EX9A4



(Note: NO ports are normally open while NC normally closed.)

Fig. 2-9 Wiring Diagram of Terminal Board EX26A3

### 2.2.2 Port Specification of Terminal Board

Group	Silk-printed Name	Software Definition	Description
External power	+24V	DC 24V power	Terminal board should be powered by external power supply.
	COM		
REF. point signal	X0	X machine origin	Binary input, low level effective; connected to home switch of X-axis.

Group	Silk-printed Name	Software Definition	Description
	Y0	Y machine origin	Binary input, low level effective; connected to home switch of Y-axis.
	Z0	Z machine origin	Binary input, low level effective; connected to home switch of Z-axis.
	COM	Common port	Signal common port.
Limit signal	XLAM+	X positive limit	Binary input, low level effective; connected to positive limit switch of X-axis.
	XLAM-	X negative limit	Binary input, low level effective; connected to negative limit switch of X-axis.
	YLAM+	Y positive limit	Binary input, low level effective; connected to positive limit switch of Y-axis.
	YLAM-	Y negative limit	Binary input, low level effective; connected to negative limit switch of Y-axis.
	ZLAM+	Z positive limit	Binary input, low level effective; connected to positive limit switch of Z-axis.
	ZLAM-	Z negative limit	Binary input, low level effective; connected to negative limit switch of Z-axis.
	COM	Common port	Common port of digital signals.
Commonly used input	SALAM	Spindle alarm	Binary input signal, connected to spindle alarm switch.
	OILAM	Oil level detection	Binary input signal, connected to sense switch of oil level.
	CUT	Tool sensor	Binary input signal, connected to tool sensor signal (tool presetter signal).
	W0	Tool over-travel protection	Binary input signal, connected to tool over-travel protection signal.
	COM	Common port	Common port of digital signals.
Spindle control	SVC	Signal output of analog voltage (from 0 to 10V)	Controlling the spindle motor speed by controlling inverter frequency due to voltage change. Externally connected to the command input port of analog voltage frequency of inverter (i.e. AVI/VI).
	GND	Analog voltage ground	Connected to analog ground of inverter (generally known as ACM).
	SPIN	Spindle CW	Relay output, its two terminals separately connected to the digital ground of inverter (i.e. DCM) and the forward rotation input port of inverter (i.e. FOR).
	OUT1	Spindle CCW	Relay output, its two terminals separately

Group	Silk-printed Name	Software Definition	Description
			connected to the digital ground of inverter (i.e. DCM) and the reverse rotation input port of inverter (i.e. REV).
Z-axis brake	BRAKE	Brake control	Relay output signal. Powered by 24V of terminal board, "Brake" port is directly connected to break coil, forming a brake circuit. The two terminals of "Brake" will be conductive after the servo of machine tool is normally on, and Z brake will be valid.
	BK+, BK-	Two ends of brake input	There are two cables for Z-axis, red or blue one for brake signal of servo output (open-collector output), black for grounding. And red or blue line should be connected to "BK+", while black line to "BK-".
Signal light	RED	Red alarm lamp	Red light on when machining ends or during E-stop.
	GREEN	Green work lamp	Light on during normal working state of machine
	YELLOW	Yellow work lamp	Yellow light on during idle state after machining ends or during waiting state.
Commonly used output	OIL	Lubrication on	Controlling auto lubrication, relay contact output, LED on during lubrication and off when lubrication stops.
	COOL	Coolant output	Relay contact output, two terminals equaling to a switch, connected to coolant output switch.
	SCOOOL	Spindle cool	Relay contact output, two terminals equaling to a switch, connected to spindle cooling switch.
	OUT2	Tool blow	Relay contact output, two terminals equaling to a switch, connected to tool blow switch.
	OUT3	Tool magazine CW	Relay contact output, two terminals equaling to a switch, connected to tool magazine CW switch
	OUT4	Tool magazine CCW	Relay contact output, two terminals equaling to a switch, connected to tool magazine CCW switch.
Reserved input	GX57/GX58	Reserved input port	Available for custom reserved input.
Cycle control	GX59/GX60	Cycle start/stop	Connected to cycle start/stop button.

## 2.3 Port Definition and Wiring Specification

### 2.3.1 Driver Interface Definition

NK260 host provides 3 pulse-feed driver interfaces, i.e. X, Y and Z axes driver interfaces. The type of driver interface is 15-core D socket (DB15 pins). The pin definition is as shown in Fig. 2-10:




Fig. 2-10 Driver Interface Definition

Table 2-1 Driver Interface Definition Specification

Name	Definition	Input /Output	Description
A+, A-	Feedback signal of encoder phase A	Input, differential signal transmission mode	Receive the differential output of encoder signal (phase A, B, C) from driver frequency divider (equal to RS422).
B+, B-	Feedback signal of encoder phase B	Input, differential signal transmission mode	
C+, C-	Feedback signal of encoder phase C	Input, differential signal transmission mode	
ALM	Driver alarm signal	Input	When breakdown occurs in driver, this output (transistor) switch will be disconnected.
SON	Servo ON signal	Output	This signal used for opening (power on) and closing (power off) servo motor. When it is connected to COM-, dynamic brake will be released and the driver is allowed to work (servo enabled).
PUL+, PUL-	Pulse output	Output, differential signal transmission mode	
DIR+, DIR-	Direction output	Output, differential signal transmission mode	
+24V, GND	DC 24V power	Output	Connected to driver



SON signal will be effective in 2 seconds after power on. Don't try to drive the motor through the external servo ON or servo OFF drive signal at any time, since the software will control the enabling state of the servo motor.

### 2.3.2 Handwheel Interface Definition

NK260 can be externally connected with a manual pulse generator (MPG, or called handwheel) via the DB15 core dual-in-line holes interface. Its pin definition is as shown in Fig. 2-11.




Fig. 2-11 Handwheel Interface Definition

Table 2-2 Handwheel Interface Definition Specification

Pin No.	Definition	Description
1	+5V	Power on the handwheel
2	HA	Encoder phase A signal
3	HB	Encoder phase B signal
4	NC	
5	NC	
6	HX1	Selection of X1 override
7	HX10	Selection of X10 override
8	HX100	Selection of X100 override
9	HSU	
10	HSA	
11	GND	Digital ground
12	HSB	
13	HSZ	Selection of Z-axis
14	HSY	Selection of Y-axis
15	HSX	Selection of X-axis

# 3 Operation

---

<b>3.1</b>	<b>Debugging Steps</b> .....	<b>26</b>
<b>3.2</b>	<b>Adjustment of Axial Direction and Pulse Equivalent</b> .....	<b>27</b>
3.2.1	Axial Direction Adjustment .....	27
3.2.2	Pulse Equivalent Adjustment .....	28
3.2.3	Upper & Lower Limit Setting of Workbench Stroke .....	30
<b>3.3</b>	<b>Returning to Machine Origin</b> .....	<b>31</b>
3.3.1	Principle of Motion of Returning to Machine Origin .....	32
3.3.2	Parameters Specifications .....	34
3.3.3	FAQ & Troubleshooting .....	36
<b>3.4</b>	<b>Spindle Parameters Adjustment</b> .....	<b>38</b>
<b>3.5</b>	<b>Port Polarity Adjustment</b> .....	<b>40</b>
<b>3.6</b>	<b>Tool Measurement</b> .....	<b>42</b>
3.6.1	Software Interface.....	43
3.6.2	Mobile Calibration.....	43
3.6.3	Fixed Calibration .....	44
3.6.4	First Calibration/ Tool Calibration after Tool Change .....	45
<b>3.7</b>	<b>Offset Setting</b> .....	<b>47</b>
3.7.1	WCS (Workpiece Coordinate System) .....	47
3.7.2	Extended WCS .....	48
3.7.3	Software Interface.....	49
<b>3.8</b>	<b>Centering</b> .....	<b>50</b>
3.8.1	Two-point Centering .....	50
3.8.2	Circle Centering .....	51
<b>3.9</b>	<b>Adjustment of Velocity &amp; Acceleration</b> .....	<b>52</b>
3.9.1	Feedrate Setting .....	52
3.9.2	Traverse Speed Setting .....	52
3.9.3	Parameters Specification.....	53
<b>3.10</b>	<b>Simulation &amp; Track</b> .....	<b>56</b>
3.10.1	Simulation .....	56

3.10.2	Motion Trace .....	57
<b>3.11</b>	<b>Compensation .....</b>	<b>58</b>
3.11.1	Screw Error Compensation .....	58
3.11.1.1	Causes of Screw Error and Compensation Method .....	58
3.11.1.2	Screw Error Compensation Operation .....	59
3.11.1.3	Software Interface and Operation .....	61
3.11.2	Tool Compensation .....	62
3.11.3	Across Quadrant Error (AQE) Compensation .....	66
<b>3.12</b>	<b>Log and Diagnosis .....</b>	<b>67</b>
3.12.1	Log .....	67
<b>3.13</b>	<b>Program File Management .....</b>	<b>68</b>
3.13.1	Program Wizard .....	68
3.13.2	Part Statistic .....	69
3.13.3	Program File .....	70
<b>3.14</b>	<b>Handwheel Operation .....</b>	<b>76</b>
3.14.1	Handwheel Mode .....	76
3.14.2	Handwheel Guide .....	78
<b>3.15</b>	<b>System Management .....</b>	<b>78</b>
3.15.1	System Info .....	78
3.15.2	Network Connection .....	79
3.15.3	Language .....	79
3.15.4	Register .....	79
<b>3.16</b>	<b>Network Connection and Share .....</b>	<b>80</b>
3.16.1	IP Setup .....	80
3.16.1.1	Direct Connection or Switch Connection .....	80
3.16.1.2	Router Connection .....	83
3.16.1.3	Multiple NK260 Connection .....	84
3.16.2	Connection Verification Setup .....	85
3.16.3	NK260 Network Files Management by PC via FTP .....	85
3.16.4	NK260 Network Files Management by PC via Network Sharing .....	86
<b>3.17</b>	<b>Auxiliary Function .....</b>	<b>87</b>
3.17.1	Start Line (Selective Processing) .....	87
3.17.2	Breakpoint Resume .....	88
3.17.3	Parameter Auto Backup .....	88



3.17.4	User Code Input .....	88
3.17.5	Coordinate Backup .....	89
<b>3.18</b>	<b>Tool Magazine .....</b>	<b>90</b>
3.18.1	Auto Tool Change of Linear Tool Magazine .....	90
3.18.2	Auto Tool Change of Circular Tool Magazine.....	92
3.18.3	Related Parameters .....	93

# 3.1 Debugging Steps




Fig. 3-1 Debugging Steps

## 3.2 Adjustment of Axial Direction and Pulse Equivalent

### 3.2.1 Axial Direction Adjustment

Firstly confirm the positive direction of each axis in terms of right-hand rule during the process of machine debugging. The coordinate system of the right-hand rule is shown in Fig. 3-2.




Fig. 3-2 The Coordinate System of the Right Hand Rule

The axial directions of machine are decided by both the type of machine tool and the layout of each component. The basic coordinate axes of engraving machine/ router are X-, Y-, and Z-axis:

——Z-axis is coincidental with spindle axis and the direction of cutter moving away from workpiece is the positive direction of Z-axis (+Z).

——X-axis is perpendicular to Z-axis and parallel to the clamped surface of workpiece. For the single column vertical milling machine, if you face the spindle and look in the column direction, right moving direction is the positive direction of X-axis (+X).

——The positive direction of Y-axis (+Y) is the direction cutter moves away from the operator.

#### ◆ Related Parameters

Parameter		Definition	Setting Range
2017	X-axis Direction	It specifies the motion direction of each axis.	“1”, “-1” represents the two motion directions of each axis.
2018	Y-axis Direction		
2019	Z-axis Direction		

Fix the positive direction of each axis following the right-hand rules, and then manually operate the machine to check if the axis moves correctly. If the direction is opposite, please modify the corresponding axis parameter in “2017~2019”. Take X-axis as an example, manually move X-axis, and find it moves oppositely, just change the value of parameter “2017” to “-1”, if its value is “1” currently.

### 3.2.2 Pulse Equivalent Adjustment

Pulse equivalent (p): the moving distance of workbench or rotation degree of rotary axis corresponding to one pulse sent by CNC device, the minimum available distance controlled by CNC system as well.

The smaller the pulse equivalent is, the higher the machining precision and surface quality will be. The larger, the faster feedrate will be. Therefore, lower pulse equivalent should be set under the condition of meeting the demand of feedrate. The relationship between Max. feedrate and pulse equivalent is as following:

$$\text{Max. Feedrate} = \text{Pulse Equivalent} \times 60 \times \text{Frequency}$$

For example, the hardware frequency of NK260 is 320 KHz and provided the pulse equivalent is 0.001 mm/p, then:

$$\text{Max. Feedrate} = 0.001 \times 60 \times 320000 = 19.2\text{m/min}$$

Mechanical deceleration (m/n): the ratio of reducer input speed to output speed, equal to the ratio of the teeth number of driven wheel to that of driving wheel. When applied in CNC machines, it specifies the ratio of motor speed to screw speed.

$$\text{Mechanical Deceleration Ratio} = \frac{\text{Reducer Input Speed}}{\text{Reducer Output Speed}} = \frac{\text{Teeth No. of Driven Wheel}}{\text{Teeth No. of Driving Wheel}} = \frac{\text{Motor Rotational Speed}}{\text{Screw Roational Speed}}$$

Pitch (d): The axial distance between the corresponding points of two adjacent teeth on the threads.

The calculation of pulse equivalent varies with different motor systems.

#### ◆ Stepping Motor

In general, firstly set the subdivision and then calculate the pulse equivalent. You can set the pulse equivalent before calculating subdivision. Their relationship can be shown as:

$$\frac{d}{p} = \frac{360}{\theta} \times x \times \frac{m}{n}$$

Hereinto, p stands for pulse equivalent, x represents subdivision of stepping motor while  $\theta$  refers to stepping angle. Therefore,

$$\text{Pulse Equivalent} = \frac{\text{Screw Pitch}}{\frac{360}{\text{Stepping Angle}} \times \text{Subdivision} \times \text{Mechanical Deceleration Ratio}}$$

For instance, the selected screw lead of X-axis for a certain type of machine tool is 5mm, and the stepping angle of stepping motor is 1.8 degree, with “10” subdivision and motor directly connected with screw by coupling. Thus, the pulse equivalent of X-axis is:

$$\text{Pulse Equivalent} = \frac{5\text{mm}}{\frac{360}{1.8} \times 10 \times 1} = 0.0025\text{mm/p}$$

#### ◆ Servo Motor

In general, set the default value of pulse equivalent as 0.001mm/p and calculate electronic gear ratio (B/A). Their relationship can be shown as:

$$\text{Electronic Gear Ratio } \frac{B}{A} = \frac{\text{Encoder Resolution}}{\frac{\text{Screw Pitch}}{\text{Pulse Equivalent}}} \times \text{Mechanical Deceleration Ratio}$$

Namely,  $\frac{B}{A} = \frac{F \times p}{d} \times \frac{m}{n}$

Electronic gear ratio (B/A): the parameter of servo driver (take YASKAWA driver as an example, B is PN202 while A PN203). This ratio represents servo scales up or down the pulse frequency sent by CNC system. When B is larger than A, it means scaling up and vice versa. For example, provided the pulse frequency sent by CNC system is 100HZ, if the numerator of electronic gear ratio (B) is set as 1 while the denominator 2, the actual running speed of servo is 50HZ. On the contrary, if the numerator is set as 2 while denominator 1, the actual running speed turns to 200HZ.

Encoder Resolution (F): needed pulse number for one circle of servo motor. Please see the servo motor label plate and then refer to the corresponding manual to confirm its encoder resolution. A label plate of YASKAWA SGMSH type motor is as below, and the 4th character in motor type is the serial encoder specification, so the resolution of this motor is  $2^{17}$ , i.e. 131072.




Fig. 3-3 Name Plate of Servo Motor-encoder Resolution

For instance: (an example of YASKAWA servo) screw pitch of a certain type of machine is 5mm, with 17 bit encoder resolution, “0.0001mm/p” pulse equivalent and “1:1” deceleration ratio.

$$\text{Electronic Gear Ratio } \frac{\text{PN202}}{\text{PN203}} = \frac{2^{17}}{5/0.0001} \times 1 = \frac{131072}{5/0.0001} \times 1 = \frac{8192}{3125}$$

◆ Rotary Axis

The pulse equivalent of rotary axis refers to the rotation degree of the axis clamping the workpiece corresponding to each pulse. The difference of rotary axis movement from linear axis movement lies in that the screw pitch of rotary axis is 360 degrees. Therefore, in calculating rotary axis pulse equivalent, you just need to replace screw pitch with 360.

- For Stepping Motor

$$\text{Pulse Equivalent} = \frac{360}{\frac{360}{\text{Stepping Angle}} \times \text{Subdivision} \times \text{Mechanical Deceleration Ratio}}$$

- For Servo Motor

$$\text{Electronic Gear Ratio } \frac{B}{A} = \frac{\text{Encoder Resolution} \times \text{Pulse Equivalent}}{360} \times \text{Mechanical Deceleration Ratio}$$

◆ **Related Parameters**

Parameter		Definition	Setting Range
2001	Pulse Equivalent (X)	It refers to the displacement or angle generated on the relative feed axis per control pulse.	0.0001~999 (mm/p)
2002	Pulse Equivalent (Y)		
2003	Pulse Equivalent (Z)		



The setting value of pulse equivalent must be matching with that of the electronic gear ratio of servo driver or that of subdivision of stepping driver.

### 3.2.3 Upper & Lower Limit Setting of Workbench Stroke

Workbench stroke refers to the valid machining stroke range of machine tool on X/ Y/ Z axis and the system will carry out software limit in terms of this range in order to protect the machine.

◆ **Related Parameters**

Parameter		Definition	Setting Range
2004	Positive Travel Limit in X-axis (MCS)	They set the allowable machine coordinate values for the upper limit of the worktable.	Negative Travel Limit (MCS) ~ 67108.864
2005	Positive Travel Limit in Y-axis (MCS)		
2006	Positive Travel Limit in Z-axis (MCS)		
2007	Negative Travel Limit in X-axis (MCS)	They set the allowable machine coordinate values for the lower limit of the worktable.	-67108.864 ~ Positive Travel Limit (MCS)
2008	Negative Travel Limit in Y-axis (MCS)		
2009	Negative Travel Limit in Z-axis (MCS)		



In the first setting of the upper & lower limit of workbench stroke, please verify the actual valid range of machine motion in case of accident.

## 3.3 Returning to Machine Origin

Origin of Machine Coordinate System (inherent coordinate system of machine tool), also called mechanical origin or mechanical zero, is fixed after design, manufacturing and debugging before machine tool leaving factory. After startup of control system, it is necessary to execute the operation of returning to machine origin automatically or manually.



The necessity of returning to machine origin:

These below functions will be available only after returning to machine origin: software limit enabled, setting the fixed point, and tool change.

### ◆ The Process of Returning to Machine Origin

The processes of returning to machine origin of X, Y, and Z axes are included and identical, shown in Fig. 3-4 (take X-axis as an example).




Fig. 3-4 The Process of Returning to Machine Origin (X-axis)

### 3.3.1 Principle of Motion of Returning to Machine Origin

The sketch maps of returning to machine origin with servo motor are as shown in Fig. 3-5 and Fig. 3-6 .



### ◆ Coarse Positioning Stage




Fig. 3-5 Sketch Map of Coarse Positioning (Stopping within the signal belt after receiving coarse positioning signal)




Fig. 3-6 Sketch Map of Coarse Positioning (Stopping out of the signal belt after receiving coarse positioning signal)

- 1) When the machine keeps moving until receiving REF. point signal at place A, it should stop immediately, but it may stop at place C or C' due to time lag and inertia.
- 2) The machine will keep moving reversely at one third of coarse positioning speed until receiving REF. point signal (if the machine has stayed within the signal belt in the above step 1, it will make no motion in this step).
- 3) The machine will keep moving reversely at one-ninth of coarse positioning speed until the REF. point signal disappears (across the signal belt).
- 4) The machine will halt at the flag place D after the end of this stage.

### ◆ Fine Positioning Stage

The process of fine positioning stage is identical with that of coarse positioning stage.

After coarse positioning, the machine will move to encoder origin rapidly, executing slow positioning several times.




Fig. 3-7 The Process of Fine Positioning

◆ **Retracting Stage**

After finishing the fine positioning stage, system will execute retracting motion once with the recommended retract distance as half of the screw pitch. The sketch map is shown in Fig. 3-8.





Fig. 3-8 Retracting Stage

### 3.3.2 Parameters Specifications

◆ **Related Parameters of Safe Operations:**

Parameter	Definition	Setting Range	
3020	Back to REF Required before Cycle Start	Whether backing to machine origin before machining is a must or not.	True: Required False: Not required
3021	Cancel REF Sign on Estop	Whether the mark of backing to the machine origin will be cleared or not once E-stop occurs.	True: Cleared False: Not cleared

Returning to the machine origin before machining can prevent machining offset, ensuring position precision. It is recommended to set "True" for parameter "3021" so that once E-stop occurs, the

Parameter	Definition	Setting Range
		mark will be cleared, and the system will remind you to back to machine origin. If “3020” is set “True” and there is no mark “  ” before each axis, the machine is not allowed to move until backing to machine origin is finished. “3020” can be set “False” when returning to machine origin is impossible due to home switch error.

◆ **Related Parameters in the Process of Backing to Machine Origin**

Parameter	Definition	Setting Range
2101	REF Switch Positioning Direction (X)	1: positive direction -1: negative direction
2102	REF Switch Positioning Direction (Y)	
2103	REF Switch Positioning Direction (Z)	
2104	Back Distance (X)	/
2105	Back Distance (Y)	
2106	Back Distance (Z)	
2107	REF Switch Positioning Speed (X)	0.001~MAX Axial Velocity (mm/min)
2108	REF Switch Positioning Speed (Y)	
2109	REF Switch Positioning Speed (Z)	
2110	REF Encoder Positioning Speed (X)	0.001~MAX Axial Velocity (mm/min)
2111	REF Encoder Positioning Speed (Y)	
2112	REF Encoder Positioning Speed (Z)	

In order to establish a machine coordinate system correctly during machine working period, a machine reference point (measuring beginning) will be set within the moving range of each coordinate axis. In machine start-up, generally returning to the reference point will be executed automatically or manually, i.e. machine tool will return to its measuring beginning (X, Y, Z=0) to establish the machine coordinate system. Machine reference point can be coincident with the machine origin (in the default system setting), or not.

When home switch works normally, if spindle moves away from home switch direction in the process of returning to the machine origin, the value of “2101~2103” (coarse positioning direction) should be modified, please refer to question No. 2 in section 3.3.3 when the moving direction of machine is incorrect during backing to the machine origin. If the speed of returning to the machine origin is quite low, you can adjust the value of “2107~2109” (coarse positioning speed) properly.

Parameter	Definition	Setting Range
“Back Distance” refers to a certain moving distance away from origin to leave the signal sensitive zone of home switch after backing to machine origin ends.		

◆ **Related Parameters to Detect Distance between Coarse and Fine Positioning Switches**

Parameter	Definition	Setting Range
2113	Pitch (X)	0.001~9999.9 (mm)
2114	Pitch (Y)	
2115	Pitch (Z)	
Related to specific machine tool, screw pitch of “2113~2115” should be set after being measured in actual operation.		

### 3.3.3 FAQ & Troubleshooting

1. REF. point signal cannot be detected in the process of returning to machine origin.

It is generally caused by home switch. The debugging & adjusting steps are shown in Fig. 3-9.




Fig. 3-9 Debugging Steps

2. Incorrect motion direction of machine in returning to machine origin may be caused by the following reasons:
  - 1) Incorrect polarity of REF. point signal: when the home switch is normally open, the polarity is “N”; when the home switch is normally closed, the polarity should be “P”.
  - 2) Incorrect parameter settings: please check the parameters “2101~2103 X/Y/Z direction in backing to reference point” and modify the corresponding parameters.
3. Low coarse positioning speed in returning to machine origin may be caused by the below reasons:
  - 1) The setting value of parameter “2107~2109 X/Y/Z speed in backing to reference point” is too small.
  - 2) The polarity setting of REF. point signal in software is mismatching with the home switch type. If the NC-type home switch is adopted and the polarity of REF. point signal is N, the REF.

point signal is valid at the beginning of backing to machine origin, so the machine will slowly move away from origin at the speed of fine positioning.

### 3.4 Spindle Parameters Adjustment

You can directly set spindle speed on the system interface.

In auto mode, press function button “State” to enter the default sub-function screen [Coor-Auto] of [State], shown in Fig. 3-10.



Fig. 3-10 Coordinate-auto Screen

You can directly set the spindle speed in the parameters setting region above the manipulation button bar, shown in Fig. 3-11.




Fig. 3-11 Parameters Setting Region-spindle Speed Setting

Press “↑”, “↓” direction key to move to the corresponding parameter setting dialogue, and then press Enter key to eject a parameter input box.

When the parameter 3019 “Ignore Spindle Speed Code(S)” is set to “YES”, the system will use the spindle speed set in the system, i.e. the value of “Spindle Speed”; when set to “NO”, the system will use the spindle speed specified by the S code in the loaded machining file.

Spindle speed is controlled by adjusting current spindle override. The formula is as below:

$$\text{Current Spindle Speed} = \text{Spindle Speed} \times \text{Current Spindle Override}$$

Spindle override selection knob is on the operation panel, shown in Fig. 3-12.




Fig. 3-12 Spindle Override Selection Knob

The least unit of ruler of spindle override is 10% (10% for each scale), and the setting range of spindle override is “50% ~ 150%”.

◆ Related Parameters

Parameter		Definition	Setting Range
3048	MAX Spindle Speed	The max. allowable rotation speed of spindle (matched with the setting value of inverter)	10000~ 999999 (r/min)
The value of “Spindle Speed” must be less than that of Para. 3048; the max. setting value of rotary speed of Para. 3048 is corresponding to analog SVC 10V; when the inverter reaches the max. voltage 10V, the corresponding rotary speed of inverter is the max. spindle speed of parameter 3048.			
$\text{Real-time Voltage of Analog SVC} = \frac{\text{Spindle Setting Speed}}{\text{Max. Spindle Speed}} \times 10V \times \text{Spindle Override}$			

◆ Related Parameters

Parameter		Definition	Setting Range
3049	Delay for Spindle On/Off	Delay time after spindle receiving “start” or “stop” command	0~60000 (ms)
3051	Spindle Action Options when Cycle Completed	After machining, spindle can be set to keep still or return to the workpiece origin or to the fixed point.	0, 1, 2
3053	Fixed Point Position in MCS (X)	When the parameter 3051 is set as 1 “move to fixed point”, the spindle will stop at the coordinates of the fixed point.	-67108.864~67108.864
3054	Fixed Point Position in MCS (Y)		
3055	Fixed Point Position in MCS (Z)		
Parameter 3049 sets the delay time of spindle on/ off, because a certain time is needed before spindle reaches the rated rotary speed since start-up or stops until reaching zero speed; if machining begins before machine reaching the rated rotary speed or other operation is executed before spindle completely stops, it’s possible to damage the tool or produce a scrap. Backing to the fixed point applies to mass production, thus, the spindle will stop at the fixed position			

Parameter	Definition	Setting Range
after each machining for the convenience to replace a new workpiece.		

◆ **Related Parameters**

Parameter	Definition	Setting Range
3043	Stop Off on Pause	Whether spindle will automatically stop when machining pauses True: Stop False: Not stop
3044	Stop Off when Cycle Stop	Whether spindle will automatically stop when machining stops True: Stop False: Not stop
This group of parameters sets the spindle action when commands of machining stop/ pause are executed.		

### 3.5 Port Polarity Adjustment

The polarity of input/ output ports in software is specified in terms of the switch type: the polarity of normally closed-type switch is “P”; the polarity of normally open-type switch is “N”. In the software interface, the ports with preceding filled dot ● are input ports, while the ones with hollow point ○ are output ports.

After wiring and power on, the red dots in front of input ports like zero signals of axes, E-stop signal, program start, program stop, and tool presetter indicate they are invalid currently, otherwise, the electrical circuit and signal polarity should be checked. If there is no problem with the electrical circuit, change the polarity of corresponding port so as to show red dots in front of the above-mentioned input ports.

If the dot in front of signal still does not change after polarity change, examine whether the port is damaged on the terminal board.

The method of modifying polarity is: press “System” function button to enter the default window [Port (A)] of [System] function section, and then use the up and down direction keys to select the I/O ports to be modified, and then press F1 to validate the port modification instantly.

[Port (A)] screen is shown in Fig. 3-13, and the following function screens need password before operation, such as [Test On], [Test Off], [Cancel Test], and [Modify Polarity].






Fig. 3-13 Ports Screen

◆ [Modify Polarity]

The shortcut key is F1, which is only available under [Port (A)] screen.

Press F1 to modify the port polarity (N / P).

The polarities of “feedrate override”, “spindle override”, “mode switch”, “handwheel” and “encoder zero” should be “N”.

Except the special definition, the polarities of output ports are generally “N”.

◆ [Test On], [Test Off]

The shortcut keys are F2 and F3 respectively, which are only available under [Port (A)] screen.

Pressing down F2 or F3 will make indicator light before the port selected shift between green and red. And green light means there is signal in the port; red light means there is no signal in the port.

This group of buttons is mainly used for analog hardware signal, which is for simulation test.



The indicator lights before ports are slight different in test mode and in practice:

Green light in test mode: Red light in test mode:   
 Green light in practice: Red light in practice:

◆ [Cancel Test]

The shortcut key is F4, which is only available under [Port (A)] screen.

Press F4 to cancel simulation test and signal to replace analog signal with real hardware signal.

◆ [Port Remapping]

The shortcut key is F5, which is only available under [Port (A)] screen.

To modify port mapping is actually modifying the physical address corresponding to the port logical address. This button is used to change the function of a certain port on the terminal board.

◆ [Board View]

The shortcut key is F7, which is only available under [Port (A)] screen.

Pressing F7 will display the terminal board screen.

### 3.6 Tool Measurement

The process of tool measurement refers to the process of establishing the concrete position of workpiece coordinate system (WCS) in the machine coordinate system (MCS).

With the help of a tool presetter, tool measurement is realized. As shown in Fig. 3-14, there are ports on the terminal board corresponding to CUT and COM on the tool presetter. If necessary, such port as “Over-travel Protection” can be added to the terminal board according to customers’ needs. According to the different installation positions of tool presetter, tool measurement is divided into mobile calibration, fixed calibration and first calibration/tool calibration after tool change.




Fig. 3-14 Electrical Wiring Diagram of Tool Presetter

Fig. 3-15 is the sketch map for calibration using tool presetter.




Fig. 3-15 Sketch Map of Using Tool Presetter

### 3.6.1 Software Interface

In auto mode, press F5 to enter “calibration interface” in [Coor-Auto (A)] sub-screen of [State], shown in Fig. 3-16 and then pressing “F1, F2, and F5” will execute “first calibration”, “second calibration” and “mobile calibration” respectively.



Fig. 3-16 Sub-screen of Tool Calibration

### 3.6.2 Mobile Calibration

Mobile calibration can be used to set the workpiece origin of Z-axis, and the thickness of tool presetter is determined by parameter [3009]. System will automatically set the workpiece offset after mobile calibration.

Workpiece offset = machine coordinate – thickness of tool presetter – public offset – tool offset

Generally, the default setting values of public offset and tool offset are both “0”.

The sketch map of the process of mobile calibration is shown in Fig. 3-17.




Fig. 3-17 The Process of Mobile Calibration

◆ Related Parameters

Parameter		Definition	Setting Range
3009	Tool Sensor Thickness	Height difference from the top surface of tool presetter to its bottom surface	0~100 (mm)
<p>The measurement method of this parameter is:                      Manually move the Z-axis to a certain point over workpiece surface→ shift down its tool nose until reaching the surface of workpiece→ the system will record the current coordinate Z1 of Z-axis.                      Uplift Z-axis→ put the tool presetter on workpiece surface→ shift down Z-axis slowly until reaching the tool presetter and getting the presetter signal→ system will record the current coordinate Z2 of Z-axis                      Subtract Z1 from Z2, and its result equals to the thickness of tool presetter. Manually enter this value into parameter 3009.</p>			

### 3.6.3 Fixed Calibration

Fixed calibration refers to the calibration operation on a certain fixed position of machine tool due to tool damage or other causes, frequently used in multi-tool mode. The length of tool and the clamping position may vary, thus tool offset should be reconfirmed by fixed calibration and the sketch map of fixed calibration is shown in Fig. 3-18.




Fig. 3-18 The Process of Fixed Calibration

The process of fixed calibration refers to input of the D-value of the recorded machine coordinate of tool nose when reaching the tool presetter surface subtracting the thickness of tool presetter into “tool offset”.

$$\text{Tool Offset} = \text{Machine Coordinate} - \text{Thickness of Tool Presetter}$$




Fig. 3-19 The Sketch Map of Tool Offset

The steps of fixed calibration are as below:

- 1) Select tool according to tool No.;
- 2) Execute fixed calibration to the selected tool and record the tool offset;
- 3) Execute step 1 and 2 to each tool;
- 4) Select any tool to move to workpiece surface for clearing.

#### ◆ Related Parameters

Parameter		Definition	Setting Range
3008	ToolMeas. TraverseSpeed to Fixed Tool Sensor	When the Z axis arrives at “Tool Sensor Fixed Position (MCS) (Z)”, it starts looking for the tool presetter signal at this speed	1 ~ Rapid JOG Feedrate (mm/min)
3009	Tool Sensor Thickness	The height of tool presetter surface in fixed calibration to the workbench surface	0~100 (mm)
3010	Tool Sensor Fixed Position (MCS) (X)	X-axis and Y-axis machine coordinates of tool presetter position in fixed calibration	Negative Travel Limit (MCS) ~ Positive Travel Limit (MCS)
3011	Tool Sensor Fixed Position (MCS) (Y)		
3012	Tool Sensor Fixed Position (MCS) (Z)	Machine coordinates of Z-axis at the beginning of searching for tool presetter signal (CUT signal). After reaching this point at G00 speed, Z-axis moves downward for tool presetter signal at “ToolMeas. TraverseSpeed to Fixed Tool Sensor”	
<p>The measurement method for parameter “3009” is as below:            Manually move the Z-axis to a certain point over the workbench surface→ shift down its tool nose until reaching the surface of workbench→ the system will record current coordinate Z1 of Z-axis.            Uplift Z-axis→ put the tool presetter on the workbench surface→ shift down Z-axis slowly until reaching the tool presetter and getting the presetter signal→ the system will record the current coordinate Z2 of Z axis            Subtract Z1 from Z2, and the result equals to the thickness of tool presetter in fixed calibration.            Manually enter this value into parameter 3009.</p>			

### 3.6.4 First Calibration/ Tool Calibration after Tool Change

The operation steps are as below:

- 1) Firstly, manually move Z axis to workpiece surface, and then confirm the workpiece origin by mobile calibration or manual clear (the method for manual clear: press F6 [Clear], and then press F4 [Z Clear] in the new pop-up manipulation button bar).

- 2) Secondly, press F5 [Preset], and then press F1 [First Time] to execute the first calibration in the new pop-up manipulation button bar, and the system will record the current machine coordinate value of Z axis automatically, as shown in Fig. 3-20. The system ends this process automatically.




Fig. 3-20 First Calibration

- 3) The first calibration finishes and workpiece machining begins.
- 4) After tool change or tool break, press F5 [Preset], and then press F2 [After Tool Change] in the new pop-up manipulation button bar to restore the Z workpiece coordinate value of current point, as shown in Fig. 3-21. The system ends this process automatically.




Fig. 3-21 Calibration after Tool Change

- 5) Tool calibration ends and workpiece machining begins.

## 3.7 Offset Setting

### 3.7.1 WCS (Workpiece Coordinate System)

In programming, programmers select one certain given point on workpiece as origin (also called programming origin) to establish a new coordinate system (i.e. workpiece coordinate system), also a set of right-hand coordinate system. The origin of WCS, i.e. workpiece origin, is fixed relative to a certain point on workpiece and floating relative to the machine origin. The selection of origin of WCS should meet the conditions of simple programming, simple dimensional conversion, and small caused machining error.

The corresponding coordinate systems of workpiece offset are G55, G56, G57, G58, G59 and G54 (the default coordinate system after the system is opened), as well as G154 ~ G173. And the relationship of workpiece offset and machine coordinate system is shown in Fig. 3-22.




Fig. 3-22 The Relationship of Workpiece Offset and Machine Coordinate System

One, two or multiple workpiece offsets can be used in machining program. As shown in Fig. 3-23, if three workpieces are installed on the workbench, then each workpiece holds a workpiece origin relative to G code of WCS. The programming example is as follows: drill one hole on each of the three workpieces, with calculation depth as Z-0.14.




Fig. 3-23 Sketch Map

```

O1801
N1 G20
N2 G17 G40 G80
N3 G90 G54 G00 X5.5 Y3.1 S1000 M03      (Select G54)
N4 G43 Z0.1 H01 M08
N5 G99 G82 R0.1 Z-0.14 P100 F8.0
N6 G55 X5.5 Y3.1      (Switch to G55)
N7 G56 X5.5 Y3.1      (Switch to G56)
N8 G80 Z1.0 M09
N9 G91 G54 G28 Z0 M05      (Switch to G54)
N10 M01
...

```

The program segment N3 ~ N5, within WCS of G54, is related to the first workpiece; Segment N6 will drill the hole on the second workpiece of the same batch in WCS of G55, while segment N7 will drill the hole on the third workpiece of the same batch in WCS of G56.

Aiming at all the coordinate systems, public offset is used for adjusting the workpiece origin of X-, Y-, and Z-axis, but will not change the workpiece offset value.

The related formula of workpiece offset, tool offset and public offset is as below:

$$\text{Workpiece coordinate} = \text{Machine coordinate} - \text{Workpiece offset} - \text{Tool offset} - \text{Public offset}$$

### 3.7.2 Extended WCS

Also known as additional workpiece coordinate system, extended WCSs (from G154 to G173) are extension for G54.

G54 Px command can be used to select the extended WCS, and “x” here refers to number 0~19.



E.g,

- G54 P0     Select the extended WCS1, corresponding to G154 on the screen.
- G54 P1     Select the extended WCS2, corresponding to G155 on the screen.
- G54 P2     Select the extended WCS3, corresponding to G156 on the screen.
- G54 Px     Select the extended WCS(x+1), corresponding to G(154 +x) on the screen.
- G54 P19    Select the extended WCS20, corresponding to G173 on the screen.

### 3.7.3 Software Interface

Press [Advanced], and then press A to enter the [Coor-Manage] screen, as shown in Fig. 3-24. This screen is mainly for selecting current WCS and modifying workpiece offset and public offset.




Fig. 3-24 Coor-Manage Screen

NK260 altogether supports 26 WCSs, i.e. G54 ~ G59 and G154 ~ G173. In [Coor-Manage] screen, the displayed WCSs are G54 ~ G59 by default. To switch to G154 ~ G173, you can press the PgUp and PgDn keys. If you want to change the value of workpiece offset and public offset, you can press “↑”, “↓”, “←” and “→” to move the cursor onto the value, press Enter and then input the desired value into the input box. For Z-axis public offset, you can also directly press F6 or F7 on the host to modify its value.

See below for the details of the manipulation buttons in the [Coor-Management] screen.

#### ◆ Select WCS

Press “←” or “→” to move cursor to the desired WCS, and then press F1 to set currently being edited coordinate system as current WCS.

#### ◆ Set X, Set Y, Set Z

Pressing shortcut keys F2, F3, and F4 will pop out an input box for entering X/Y/Z workpiece offset.

◆ **Select Distance, Deepen, Lift**

Pressing the shortcut key F5 of “SelectDistance” will change the value of “Lift and Deepen Height of Z-axis”, with five options, which are 0.01mm, 0.10mm, 0.50mm, 1.00mm and 5.00mm.

Pressing the shortcut key F6 of “Deepen” will move down Z-axis workpiece origin by “Lift and Deepen Height of Z-axis” distance. The moving distance will be accumulated accordingly with the press times of F6.

Pressing the shortcut key F7 of “Lift” will move up Z-axis workpiece origin by “Lift and Deepen Height of Z-axis” distance. The moving distance will be accumulated accordingly with the press times of F7.

Both “Deepen” and “Lift” only modify public offset of Z-axis.

## 3.8 Centering

The system supports “Two-point Centering” and “Circle Centering”, both of which belong to manual centering. An edge finder can be used for accurate centering.

Before manual centering, you should press F5 [Center Start] to make it turn to orange and turn on spindle, spindle speed decided by the parameter 3052 “CenterSpindlerev”, whose value is 500 by default and should not be set too large.

### 3.8.1 Two-point Centering

Two-point centering refers to the process of locating the midpoint of a line connected by two points, mainly used for locating the center of a blank.

In manual mode, press [Advanced], and then the letter “B” to enter the “Centering (B)” screen, with “Centering (T)” as the default centering mode. See Fig. 3-25.



Fig. 3-25 Centering Interface

The operation steps of two-point centering are as below (An example of X-axis):

- 1) Manually move the cutter to one side of workpiece, and then press F1 [Record X] to record the machine coordinate of current point.
- 2) Move the cutter to the other side of workpiece, and then press F2 [Center X] to calculate the midpoint coordinate based on the coordinate of current position and the last recorded value and set it as workpiece origin.



In the process of centering of a certain axis, the other coordinate axis should keep still.

### 3.8.2 Circle Centering

Circle centering, i.e. three-point centering, means automatic calculation of center point coordinates (generally set as workpiece origin) of a circular blank in terms of the three recorded circle coordinates.

In auto mode, press [Advanced], and then the letter “B” to enter the “Centering (B)” screen, and then the letter key “S” to turn to “Circle Centering” mode. See Fig. 3-26.




Fig. 3-26 Circle Centering Interface

The steps of circle centering are as below (An example of X-axis):

- 1) Manually move the cutter to one point on the circumference of a circular blank, and then press F1 [Record 1] to record the machine coordinates of current point as the first group of coordinate;
- 2) Move the cutter to another point on the circumference, and then press F2 [Record 2] to record the machine coordinates of current point as the second group of coordinate;
- 3) Move the cutter to the third point on the circumference, and then press F3 [Center] to calculate the circle center coordinates and set it as workpiece origin based on the current machine coordinates and the two groups of coordinate recorded previously.



The three points on the circumference should be apart from each other as far as possible for the accuracy of the circle center.

## 3.9 Adjustment of Velocity & Acceleration

### 3.9.1 Feedrate Setting

Feedrate can be set directly on the system interface, or through changing the value of parameter 1004 “Default Feedrate (GXX)”.

In the function section of [State] under auto mode, the feed rate can be directly specified on the parameters setting region above the manipulation button bar, shown in Fig. 3-27.



Fig. 3-27 Parameters Setting Section-feed Speed Setting

Press “↑”, “↓” direction key to move to the corresponding parameter setting frame, and then press Enter key to eject the parameter input box.

When the parameter 3018 “Ignore Feedrate Code(F)” is set to “YES”, the system will use the feedrate set in the system, i.e. the value of “Feed Speed”; when set to “NO”, the system will use the feedrate specified by the F code in the loaded machining file.

The feed rate is also related with current feedrate override, which can be controlled by adjusting the current feedrate override, and the formula is as below:

$$\text{Current feed rate (feed speed)} = \text{Set feed value} \times \text{Current feedrate override}$$

The feedrate override selection knob is on operation panel, shown in Fig. 3-28.




Fig. 3-28 Feedrate Override Selection Knob

The adjusting range of feedrate override is “0% ~ 120%”.

### 3.9.2 Traverse Speed Setting

Traverse speed refers to the running speed of machine tool under G00 command.

Similar to feed speed, traverse speed can also be set directly on the system interface, as shown in Fig. 3-29, or through changing the value of parameter 1003 “Default Rapid Traverse Feedrate (G00)”.



Fig. 3-29 Parameters Setting Area-G00 Speed Setting

Its concrete setting method is the same as that of feed speed, which will be omitted.

### 3.9.3 Parameters Specification

Except for the feed rate and traverse speed, the other involved parameters can be divided into following 4 types: velocity, acceleration, reference circle & circular speed limit, and interpolation algorithm.

#### ◆ Related Parameters of Velocity

Parameter		Definition	Setting Range
1001	Rapid JOG Feedrate	There are two speed modes for option under manual mode: jog feedrate and rapid jog feedrate, which can be switched by pressing the acceleration key. The system default running speed mode is jog feedrate mode.	JOG Feedrate ~ MAX Axial Velocity (mm/min)
1002	JOG Feedrate		0.001~ Rapid JOG Feedrate (mm/min)
3006	Startup Speed	The minimum speed in machining.	0~Z-axis Approach Speed (mm/min)
3016	Traverse Feedrate Override Fixed 100%	When it is set as “True”, G00 override will be not controlled by the override switch, but fixed at 100%.	True: Valid False: Invalid
3017	JOG Feedrate Override Fixed 100%	When it is set as “True”, feedrate override is adjusted in manual operation; “False”, feedrate override is fixed at 100%.	True: Valid False: Invalid
3018	Ignore Feedrate Code (F)	When it is set as “True”, the system will not adopt feedrate specified by the F code in the loaded machining file, but use the feed speed set in the system.	True: Valid False: Invalid
3019	Ignore Spindle Speed Code (S)	When it is set as “True”, the system will not adopt spindle speed specified by the S code in the loaded machining file, but use the spindle speed set in the system.	True: Valid False: Invalid
3029	Z Down Feedrate Limitation Options	0: No limitation; 1: Z Down Feedrate Limitation valid with only Z-axis downward movement; 2: Z Down Feedrate Limitation valid with Z-axis	0; 1; 2

Parameter		Definition	Setting Range
		downward movement included	
3030	Z Down Feedrate Limitation	Z axis downward movement speed.	0~MAX Axial Velocity (Z) (mm/min)
3031	Z-axis Deceleration Distance	To protect tools, the machine tool will decelerate (at [approach speed]) when approaching the target position during positioning. This parameter is used to specify the distance from the decelerating position to the target position.	0~999 (mm)
3032	Z-axis Approach Speed	It is the feed speed when the distance between the tool and the workpiece is smaller than “deceleration distance” during positioning.	0~Default Feedrate (mm/min)
3033	MAX Axial Velocity (X)	It specifies the max. allowable speed of X axis.	6~15000 (mm/min)
3034	MAX Axial Velocity (Y)	It specifies the max. allowable speed of Y axis.	6~15000 (mm/min)
3035	MAX Axial Velocity (Z)	It specifies the max. allowable speed of Z axis.	Z Down Feedrate Limitation~15000 (mm/min)
3038	Enable Short Line Velocity Smoothing	When it is set as “True”, the system will eliminate the fluctuation of speed when machining short line segments.	True: Valid False: Invalid
3039	Short Line Ref. Length in Velocity Smoothing	Short line segments shorter than the value of this parameter will be treated with velocity smoothing.	0.001~100000 (mm)

Parameter 3006 “startup speed” aims at the startup frequency of stepping & servo driver, and in driver this parameter should be set zero. The startup speed refers to the highest frequency of direct working startup without acceleration of motor.

Parameter confirmation method: set a lower value at first, and repeatedly make the machine execute typical motion & multi-axis synchronization motion, gradually increase this value until fix the max. startup speed. The actual setting value of this parameter is half of the max. startup speed, with general setting range “300 ~ 400”.

Reasonable selection of this parameter will improve the machining efficiency, and avoid the low speed segment with bad motion feature of motor. “Startup frequency” is generally included in the motor ex-factory parameters, but after installation, its value will vary especially in loading motion, thus, it should be set based on the actual measurement of motor power and inertia of machine tool.

#### ◆ Related Parameters of Acceleration

Parameter		Definition	Setting Range
3002	Axis Acceleration	The max. acceleration of each axis in machining.	0.001~100000 (mm/s <sup>2</sup> )

Parameter		Definition	Setting Range
3003	Dry Run Acceleration	The max. acceleration of each axis in positioning.	0.001~100000 (mm/s <sup>2</sup> )
3004	Max Turning Acceleration	Max. turning acceleration.	0.001~100000 (mm/s <sup>2</sup> )
<p>Single axis acceleration includes “Axis Acceleration” and “Dry Run Acceleration”, used to describe the acceleration/ deceleration capability of each feed axis, with unit “mm/s<sup>2</sup>”, depending on the physical feature of machine, such as the quality of motion part, torque, cutting load and resistance of the feed motor. The larger the value of the parameter is, the less time the machine will spend in acceleration/ deceleration during motion process, the higher the efficiency is. Generally, for servo motor system, it should be within “600 ~ 3500”. Set a smaller value at first, and then repeatedly execute typical motion for a period of time. If there is no abnormal situation, gradually increase the value. If abnormal condition occurs, reduce the value, with “50% ~ 100%” insurance allowance.</p>			

◆ **Related Parameters of Reference Circle, Circular Speed Limit**

Parameter		Definition	Setting Range
3036	Enable Arc Velocity Limitation	Whether to enable arc velocity limitation.	True: Valid False: Invalid
3037	MAX Velocity of Ref. Circle	The max. velocity when machining a circle 10mm in diameter.	/
<p>After installation of machine, you can make the machine process an arc, in which vibration will occur due to centrifugal force. The higher the speed is, the stronger the vibration will be. Gradually increase the feed speed to see the state of vibration of machine tool until the max. circular speed is achieved, i.e. the max. allowable speed of machine tool without strong vibration. This arc is regarded as the reference circle, and its max. allowable speed is the max. speed of reference circle. Max. centripetal acceleration “a” can be calculated in terms of the reference circle radius and its max speed. The formula is as follows: <math>V_0</math> and <math>R_0</math> are the speed and radius of reference circle respectively, while <math>V_x</math> and <math>R_x</math> are the speed and radius of the arc to be processed. After <math>R_x</math> is confirmed, when the arc processing speed is larger than <math>V_x</math> calculated, the system will limit the arc processing speed automatically to ensure it is within the debugging value, i.e. the vibration will not be stronger than that during ex-factory debugging.</p> $a = \frac{V_0^2}{R_0} = \frac{V_x^2}{R_x}$			

◆ **Related Parameters of Interpolation Algorithm**

Parameter		Definition	Setting Range
3028	Path Interpolation Algorithm Options	It sets which interpolation algorithm is used.	0: Velocity triangle; 1: Velocity S-type

Parameter	Definition	Setting Range
	Currently, the system supports velocity triangle algorithm and velocity S-type algorithm. When S-type algorithm is adopted, the system max. acceleration will reach the twice of the single axis acceleration set in the system. At this time, setting a smaller value for parameter 3002 “Axis Acceleration” and 3003 “Dry Run Acceleration” is recommended.	

## 3.10 Simulation & Track

### 3.10.1 Simulation

The function of simulating provides a fast but lifelike simulated processing environment for you.

Running under the mode of simulating, the system will not drive the machine tool to do the relative actions but only show the processing trace of the cutter in high speed in the trace window. By simulating, you see moving form of the machine tool in advance, avoiding machine tool damage due to programming mistakes in processing procedure. And they can also know other additional information.

The steps of simulation are as below:

- 1) Press “↑” and “↓” shift keys under [Local Program (A)] of [Program] function section to select a machining file, and then press F1 [Load] to load the file;




Fig. 3-30 Program File Window

- 2) Press F1 [Simulate] under [Motion Trace (B)] sub-function screen of [State] function section to begin simulation, in which tool machining path can also be viewed. At the same time, such information as processing range and estimate processing time can be viewed under [Current Program (C)] sub-function screen.






Fig. 3-31 Simulation Track




Fig. 3-32 Current Program Screen

Press F7 [Quit Simulation] to exit from simulation.

### 3.10.2 Motion Trace

[Motion Trace] screen can give a 3D display on the processing track followed in real time, with which you can view the tool path more intuitively so as to ensure the accuracy of processing program. In 3D tracking mode, abundant operation methods are offered by the system for the convenience of you to view the motion track from different viewing angles and in an appropriate scaling. P and Q keys can be used to switch the angle of view.

# 3.11 Compensation

## 3.11.1 Screw Error Compensation

### 3.11.1.1 Causes of Screw Error and Compensation Method

Screw error consists of screw pitch error and errors caused by backlash. Generally, these two errors don't need compensation, but backlash compensation is needed in high precision required situation, if higher precision is required, both the two compensations are needed.

◆ **Pitch Compensation:**

Pitch error is caused by defect in manufacturing of screw and long-term wear, etc. In order to improve precision, pitch compensation is needed. The sketch of screw is shown in Fig. 3-33(A). A coordinate system is established, based on "0" point on the screw as the reference point, nominal value as X-coordinate, and actual value as Y-coordinate. Then ideal moving curve is as curve "1" in Fig. 3-33(B), however, actual curve will be curve "2" due to pitch error. That is to say, the Actual value is not the same as its corresponding Nominal value, actual moving curve deviating from the ideal one, and their difference is called error, i.e.:

$$\text{Error} = \text{Nominal Mechanical Coordinate} - \text{Actual Mechanical Coordinate}$$




Fig. 3-33 Analysis of Pitch Error

◆ **Pitch Error Compensation Method:**

In pitch compensation, generally pitch error value isn't related to feed direction. That is, when the pitch is too small in positive feed, additional pulse is needed, and thus, when negative feed passes the same position, the same amount of feed pulse should be added. But if the pitch is large, deduction of pulse is needed, and neither is the reducing amount related to feed direction. In software compensation, correction of each point on the error curve should be tabulated and saved to the system memory. Then auto compensation for coordinates of each point is available in running, so as to improve machine precision.

### ◆ Backlash Compensation:

Hysteresis feature is caused by forward and reverse clearance. Assume that driving shaft drives driven shaft in negative (CW) rotation, servo motor will be idling without moving worktable because of mechanical driving chain backlash, when the driving shaft suddenly begins CCW rotation (positive motion). After staying at a certain position for some time, the worktable will move backward with the driving shaft; when the direction of the driving shaft changes again, the situation is the same, which is called Hysteresis. If pitch error doesn't exist, under ideal condition, the moving curve of worktable is shown in Fig. 3-34(A), in which the curve of horizontal section is during the idling of servo motor without worktable movement. The actual moving curve of worktable is shown in Fig. 3-34(B).




Fig. 3-34 Analysis of Backlash

The popular explanation is: because spindle is generally fixed on the screw whose outer wire and the inner wire on the outer wire cannot be completely matched, backlash compensation compensates the clearance between the screws of last direction that the spindle needs to finish after reversing its moving direction.

### ◆ Measuring Method and Compensation Method of Backlash

Backlash can be measured by a specialized gauge. Firstly, fix the instrument nearby the spindle. Secondly, make the watch hand at the zero point position. Thirdly, manually move “a” millimeter, then move “a” millimeter back, and then see the actual moving distance of watch hand: “b” millimeter. Therefore, the backlash is measured, namely (a-b) millimeter.

If one axis moves from positive to negative, “+Q” pulse will be output before reversal; conversely, from negative to positive, “-Q” pulse will be output before reversal (Q is backlash, preset by program).

#### 3.11.1.2 Screw Error Compensation Operation

Actually the system has already combined the above two errors (screw pitch error and backlash) to deal with. The system will execute error compensation automatically based on the error data in the file after the backward error and forward error of the corresponding nominal coordinate of each coordinate axis are listed into the screw error compensation file.

The detailed operation is: save the measured value of compensation in file “axeserr.dat” in directory of USB disk which is connected to the system. The system will execute compensation as the file described immediately.

◆ **Screw Error Compensation File “axeserr.dat”**

The name of the screw error compensation file is “axeserr.dat”, found under the installation directory. Modification to the data in the screw error compensation file will become valid after the software is restarted.

The file format is:

- 1) Firstly specify length unit, currently the supported length unit is mm and the style of writing is: unit = mm
- 2) Then specify error sequence of each axis. To work properly, the contents in this sequence must be in the ascending order of nominal machine coordinate value. Refer to Table 3-1 for details.
- 3) Annotation: it must be in a separate line and started with a semicolon. Its syntax is:

; <Annotation contents>

Note that a semicolon must be the first character of the separate line, that is, no other character should be in front of the semicolon, even blank space.

Table 3-1 Explanation about Axis Error Sequence

Item	Specification
<b>Axis Name</b>	X, Y, Z, (Case-insensitive)
<b>Nominal Machine Coordinate</b>	It is the machine coordinate with a sign with respect to reference point, which is calculated by the given pitch and pulse equivalent (i.e. the length calculated based on the nominal pitch, not on the actual physical one), arranged in ascending order. Nominal machine coordinate must be within the stroke range, or the compensation is invalid.
<b>Backward</b>	The error generated by the motion towards decreasing direction of coordinate
<b>Forward Error</b>	The error generated by the motion towards growing direction of coordinate value.
<p><b>1. The style of writing of each axis error sequence:</b>                      [Axis Name]                      &lt;Nominal Machine Coordinate&gt;, &lt; Forward Error&gt;, &lt; Backward Error&gt;                      &lt;Nominal Machine Coordinate&gt;, &lt; Forward Error &gt;, &lt; Backward Error &gt;                      &lt;Nominal Machine Coordinate&gt;, &lt; Forward Error &gt;, &lt; Backward Error &gt;</p> <p><b>2. The sign of nominal machine coordinate and actual machine coordinate</b>                      Pay special attention to the sign of nominal machine coordinate and actual machine coordinate, especially when equipment like laser interferometer is used to measure the length. Calculate after the measured length is converted to the corresponding machine coordinates, or a wrong result may occur.</p>	

Table 3-2 Example of Screw Error Compensation File Format

Condition	Example	Remark
Common cases	;unit=mm [X] -570.025, 0.027, 0.083	-

Condition	Example			Remark
	-450.020, -330.015, -210.010,	0.025, 0.015, 0.000,	0.077 0.068 0.057	
A certain axis only needs backlash compensation	;unit=mm [Y] 0.000,      0.000,      0.030 1000.00,    0.000,      0.030			Only the data of start point and end point of this axis needs writing down. If the backlash compensation on Y-axis is 0.03mm, the setting range is 0 → 1000.

### 3.11.1.3 Software Interface and Operation

Turn to [Compensation (=)] screen under [Parameters] function section, then press F7 (Leadscrew button), and then press F3 to set the compensation parameters, as shown in Fig. 3-35.



Fig. 3-35 Compensation Parameters Setting

#### ◆ Insert

Continuous inserting of multi-blank-line prohibited; next inserting is allowed after previous one is completed.

#### ◆ Import & Outport

Compensation files can be copied from or to a U disk or other external storage.

#### ◆ Apply

Apply, i.e. save. After parameters are set, press Apply before restarting the software. Reboot is needed to validate the modification of backlash data. If the system is not rebooted, the modified value does not take effect, while it is the previous backlash data that still works.



- 1) The compensation data can be in an ascending or descending order. Positive interval indicates ascending order while negative interval descending order.
- 2) Backlash can only be set in unilateral compensation, and hidden in bilateral compensation.
- 3) Remember to press the Apply button after modification of screw error compensation data. Before machining, homing should be executed, because the system only sends the compensation data of the homed axes to the driver.
- 4) After switchover between unilateral compensation and bilateral compensation, it is necessary to load the desired file again and apply it. Otherwise, it is the previous compensation mode and data before modification that still work.

◆ **Related parameters are:**

Parameter		Meaning	Setting Range
4101	Screw Error Compensation Options	Decides whether to execute screw error compensation, including unilateral compensation and two-way compensation.	0: No compensation; 1: Single compensation; 2: Double compensation
4102	Enable Backlash Compensation	It sets whether to enable backlash compensation.	True: Valid False: Invalid
Press F7 (Leadscrew button) under Compensation (=) interface	Backlash	It sets the value of backlash of each axis, only valid when parameter [Enable Backlash Compensation] is set "True".	0~1000 ( μ m)
<p>If parameter "4101 Screw Error Compensation Options" is set as "0", and parameter "4102 Enable Backlash Compensation" as "True", only backlash compensation is activated.</p> <p>If 4101 is set as "1", and 4102 as "True", backlash compensation and unilateral error compensation are activated, used when backlash is relatively constant.</p> <p>If 4101 is "2", forward error compensation and backward error compensation are executed together, used when backlash is not constant.</p>			

### 3.11.2 Tool Compensation

In CNC machining, the CNC system actually controls tool center or the related point of tool rest whose motion track is controlled directly to indirectly realize the profile processing for the actual parts.

The cutting part tools actually used are tool nose or cutting edge which has dimensional variation with tool center or the related point of tool rest, so the control system has to compute the corresponding coordinates of tool center or the related point of tool rest according to the actual coordinate position of

tool nose or cutting edge (namely the actual coordinate position of parts profile), which is called tool compensation.

Input the new tool parameter values in [Compensation (=)] input interface (as shown in Fig. 3-36) if tool nose radius is altered after tool wear, tool sharpening or tool change, avoiding the trouble to modify the programmed processing procedure.




Fig. 3-36 Tool Parameters Screen

To make tool compensation (including tool diameter compensation and tool length compensation) effective, parameter “4500 turn on radius compensation” should be set as “true”. Code G43 (positive offset) and G44 (negative offset) are used for tool length compensation; G41 (left compensation) and G42 (right compensation) for tool radius compensation; G40 (cancel tool radius compensation) and G49 (cancel tool length compensation) are used for canceling tool compensation.

Only when tool compensation codes and G00/G01 are used together can the tool compensation be enabled.

◆ Involved Parameters:

Parameter		Meaning	Setting Range
4500	Turn on radius compensation	Setting whether to perform tool compensation	True: Valid False: Invalid
4501	Specify the type of tool compensation	1: General mode; 2: Intersect mode; 3: Insert mode	1; 2; 3
Under “Compen-sation (=)” Interface	Diameter	Tool diameter	0.000~9999.000 (mm)
	Dia_Wear	The system can compensate the tool diameter according to the input value of this parameter after measurement.	0.000~9999.000 (mm)
	Length	Tool length	0.000~9999.000 (mm)
	Len_Wear	The system can compensate the tool length according to the input value of	0.000~9999.000 (mm)

Parameter	Meaning	Setting Range
	this parameter after measurement.	

◆ **Tool Radius Compensation (Code G40~G42)**

Tool radius compensation code, namely from G40 to G42, can make the tool moved by the offset value, see in Fig. 3-37.

To make the offset value is the same with the tool radius value, the system will firstly create a offset vector (known as “Starting”), whose length equals to radius of the tool.

Direction of the offset vector is perpendicular to the forward direction of the tool, looking into the tool center from the workpiece.

If linear interpolation or circular interpolation is called after “Starting”, the system will contour with the tool moved by the offset, namely, with the tool compensated by radius value.

To end the compensation and make the tool return to the starting point, tool radius compensation code will be canceled and disabled.




Fig. 3-37 Schematic Diagram for Tool Radius Compensation

◆ **Tool compensation types**

Tool (cutter) compensation should be established before executed and canceled after workpiece machining completed. To establish tool compensation is to move the tool to the edge of workpiece in a reasonable way, while to cancel tool compensation is to move the tool to the specified point from the edge of workpiece.

Generally speaking, tool compensation establishment consists of two segments, see segment 1 and segment 2 in Fig. 3-38. The software offers 3 ways to establish and cancel the tool compensation:

- 1) Normal type: the programming path is translated by 90 degrees to get the segment 2 for establishment, next, make the starting point of segment 2 the end point of the segment 1. Segment 1 and 2 constitute the tool nose path with tool radius compensated. Please note that



this type is not available to arc command.

- 2) Intersect type: the programming path is translated in parallel to get the segment 2 for establishment, next, make the starting point of segment 2 the end point of the segment 1. Segment 1 and 2 constitute the tool nose path with tool radius compensated. Please note that this type is not available to arc command.
- 3) Insert type: after the programming path is translated, figure out the intersection point of segment 1 and 2. Insert a line from the starting point of segment 1 before translation and the starting point of segment 1 after translation, to get the tool nose path. It is available to arc command as well, but machining efficiency will be affected since an extra segment needs to be completed.




Fig. 3-38 Types of Enabling Tool Compensation

◆ **Direction of tool compensation**

The schematic diagram of tool compensation direction is as shown in Fig. 3-39.




Fig. 3-39 Direction of Tool Compensation (a: Left compensation b: Right compensation)

Programming for tool radius compensation is as shown in Fig. 3-40:




Fig. 3-40 Schematic Diagram of Tool Compensation Processing

```
G17 G01 G41(G42) X10 Y10 F1000 D01 ' linear interpolation and tool radius compensation
G02 X_ Y_ I_ J_ ' circular interpolation
```

Among the above in shadow, G41 means left compensation, namely the tool will deviate a distance towards the left side of tool heading direction and this distance is tool radius; G42 means right compensation, namely the tool will deviate a distance towards the right side of tool heading direction and this distance is tool radius. X10Y10 is the endpoint coordinates of linear motion. F1000 represents the tool moves at the speed of 1000 mm/min. D01 is the parameter of G41/G42, namely the tool compensation number. From D00 to D07, they have their own corresponding radius compensation value in the tool compensation table.

For the details of programming of tool compensation instruction, see *Programming Manual*.

### 3.11.3 Across Quadrant Error (AQE) Compensation

When a circle is processed, distortion, like a spike, may occur at the transition position from one quadrant to another one. AQE (across quadrant error) compensation can solve this kind of distortion.

AQE compensation includes parameters to eliminate the spike near the transition position from one quadrant to another one in circular machining. The settings of each axis in positive and negative directions are all similar.

◆ **Involved Parameters:**

There are altogether 6 groups of compensation parameters, each of which includes time, length, delay time and intensity. Group 0 is listed below for reference.

Parameter		Meaning	Setting Range
4103	Enable Quadrant compensation	Whether to enable AQE compensation	True: Valid False: Invalid
4104	Quadrant compensation time	As its name implies.	0 ~ 0.3015 (sec)
4105	Quadrant compensation length	As its name implies.	0 ~ 10 (mm)
4106	Quadrant Compensation Delay	As its name implies.	0 ~ 10 (sec)
4107	Quadrant compensation Intensity	As its name implies.	0 ~ 1

To enable AQE compensation, set parameter 4103 as "True".  
Compensation time: the larger the value is, the larger the compensation-affected area will be.

Parameter	Meaning	Setting Range
Recommended value is 0.02 sec.		
Compensation length: the larger its value is, the more obvious the compensation result will be. However, note that too large value will make the arc concaved, while too small value will not suppress the spike effectively. It is suggested to measure the actual height of the spike with a laser interferometer or other measuring device in debugging, and then set this parameter as 0.3 to 3 times of spike height. Compensation result is also related with compensation time and intensity.		
Compensation delay time: the spikes may not appear exactly at the four quadrant positions due to mechanical properties of machine tool, but a little distance away from the quadrant points. Estimate the time to travel this distance and then set the time as the value of this parameter.		
Compensation intensity: the larger the value is, the more obvious the compensation result will be.		

## 3.12 Log and Diagnosis

### 3.12.1 Log

Press “System” function key to enter [System] function section, and then press letter key B to enter [Log] sub-function screen.

As shown in Fig. 3-41, [Log] screen under [System] function section records important operations and system events, and you cannot only browse the log information since this time start-up but also view the history records.




Fig. 3-41 Log Screen

#### ◆ Show Info, Show Warning and Show Error

Their shortcut keys are F3, F4 and F5 respectively.

The three buttons correspond to the three kinds of information accordingly, namely general information, warning information and error information.

#### ◆ Show System

Pressing F6 can view the system information, which needs password.

#### ◆ Delete Log

Pressing shortcut key F7 will delete all the logs.

## 3.13 Program File Management

Program file management manages the processing files in the system, related to the operation of processing program.

### 3.13.1 Program Wizard

NK260 offers 5 basic processing program wizards: circular frame, circular pocket, rectangular frame, rectangular pocket and laser measure. You just need to input some simple parameters to complete the milling operation of circular frame and rectangular frame, etc. Take laser measure as an example in the following:

Press “Program” key to enter [Local Program] screen, and then press letter key C to enter [Prog Wizard] screen, and then press shortcut key L to switch to laser measure screen, as shown below. You can set parameters for the selected object as required to achieve the desired result.




Fig. 3-42 Laser Measure Screen

[LaMeasure]: the wizard for screw error measured by a laser interferometer. The data file generated with this wizard can be used for backlash compensation.

After the input of Start Position, End Position, Num Points, Num Runs and Pause Interval, the system will automatically record the error of each num point (measured point) and then output the compensation file by the laser interferometer.

After parameter values are entered, press F3 to save them, the system automatically generating the program, then press F1 to load the program, and then press “Program Start” to begin measuring.



- 1) Select an axis first, and only one axis can be selected at one time.
- 2) Start Position and End Position should be both within the stroke range, and the latter one should be larger than the former one.
- 3) One Num Run refers to the process from Start Position to End Position and to Start Position again. The laser interferometer will record a group of data in each Num Run. The screw error compensation file uses their average value.
- 4) Measuring interval = (End Position – Start Position)/ (Num Points -1). If precise measuring is needed, Start and End Position should be calculated accurately so as to ensure the coordinates of measured points are integers.

Checking inner circle of circle frame refers to milling the inner area while outer circle for milling the outer frame. Circle pocket requires setting the X and Y workpiece coordinates. The operation method and parameter setting principle of round bottom milling, rectangular frame milling and round frame milling are the same as those of rectangular bottom milling, except for some parameters to be set.

### 3.13.2 Part Statistic

This screen mainly displays the statistics of current machining file and previously machined files.

Press [State] button in Auto mode, and then press “=” to enter [Part Statistic] screen, as shown in Fig. 3-43. The upper part of this screen displays the machining info about the machined files, including file name, total machining time, total machining length and machined times, while the lower part shows the info about current machining file, like name, single time, total time, single length, total length, cycles and part count. Among them, the counterpart of “Cycles” is the “Prog Cycle Times” under “Coor-Auto (A)” screen.

Pressing F1 will clear all historical statistics records on the list.

Pressing F2 can export statistics of all machined program files to a U disk or other external storage in .txt format.




Fig. 3-43 Part Statistic Screen

### 3.13.3 Program File

Press function key “Program” to enter [Program File] function section, mainly including [Local Program (A)] and [USB File (B)] to be introduced.

[Local Program] is the default screen after entering [Program File] function section, as shown in Fig. 3-44. On the upper part of this screen, there is file list box displaying the processing files under the path D:\NCFILES. On the lower part, the prompt box shows the path of the currently selected file and the available space of driver. “Progress” bar displays the schedule of “Load” and “Unload” operations. Folders can be opened by pressing “Enter”.




Fig. 3-44 Local Program Screen

You can find the processing files under the default path of hard disk and execute such operations as loading, editing, deleting and renaming them. In addition, you can create a new processing file under the default path D:\NCFILES and edit it.

**◆ Load**

After the processing file is selected (press “↑” or “↓” key to move cursor to the target file), pressing shortcut key F1 will make the system load the file automatically, progress bar on the lower right part displaying the schedule. After loading finishes, other operations are available.

**◆ Delete**

After selecting a file, press F3 to eject a prompt box asking you whether to delete the file.



If the selected file is under the state of being loaded or edited, deleting it is prohibited.

**◆ Edit**

After the processing file is selected, pressing shortcut key F4 will make the system eject its embedded program editor automatically, in which you can edit the contents in the file. After editing, press F1 to save and confirm the modification and return to [Local Program] interface automatically.



The file being loaded cannot be edited. Unload it before editing it if necessary.

**◆ Rename**

After selecting a processing file, press shortcut key F5 to eject a file name input box asking you to input the new name, and then pressing F1 will complete the operation.

**◆ New**

After shortcut key F7 is pressed, the system will switch to edit page. You can enter the program here. See Fig. 3-45.




Fig. 3-45 Create a New Program

After finishing entering the program, you can press F1 “Save” to save the program. Enter the program name (all in capital letters) in the pop-up dialog, as shown in Fig. 3-46, and then press Enter for confirmation.




Fig. 3-46 Save Program

If you want to look for a certain program block, you can press F4 “Find”. Enter the find content, and then press “Enter”. In the “Find” page, you can press F5 “Next” to look for the next one, or F7 “Back” to go back. See Fig. 3-47.






Fig. 3-47 Find Page

If you want to replace a certain program block, you can press F5 “Replace”. Enter the find content and replace content, and then press “Enter”. In the replace page, press F6 “Replace” to replace the find content with the replace content, and then press F5 “Next” to find the next place, and then press F6 to execute replacement. You can continue this process until all the find content are replaced by the replace content, or press F7 “Back” to go back. See Fig. 3-48.




Fig. 3-48 Replace Page

If you want to clear the contents in the edit page, you can press F6 “Clear Contents”.

◆ **Unload and Copy to USB**

Pressing shortcut key F2 will unload the file currently being processed, corresponding to the operation of “Load”.

Pressing shortcut key F6 (the premise is that a removable disk has already been inserted) will copy the file selected to the removable disk.

Press letter key B to enter [USB File (B)] screen, as shown in Fig. 3-49, in which files in the USB flash disk can be read in. You can also do the following operations to them, like “Load”, “unload”, “Edit”,

“Delete”, “New”, “Rename”, and “Copy to local”. Folders can be opened by pressing “Enter”.



Fig. 3-49 USB File Screen

◆ Involved Parameters are: Translation Parameters of DXF File

Parameter		Meaning	Setting Range
5001	Tool lifting height	It sets the tool lifting height during rapid traverse.	0~99999 (mm)
5002	Machining depth	It specifies the processing depth for 2D files.	-99999~0 (mm)
5003	Use first point as zero point	It sets whether to set the firstly met coordinate point as zero point when DXF file is processed.	True: Use the first point as zero point False: Not use the first point as zero point
5004	Shape separate processing_valid	It sets whether the system will completely process the last workpiece before machining the next one(s).	True: Valid False: Invalid
5005	Bottom machining valid	Valve operation is enabled only when [2D cutting] is on the workpiece surface.	True: Valid False: Invalid
5006	Use dxf file as metric size	It forcibly sets dxf file as metric size.	True: Forcibly set as metric size False: Not forcibly set as metric size

Translation parameters of DXF file are applied to translation for DXF files, including “Tool lifting height”, “Machining depth”, “Layer depth”, “Use first point as zero point” and “Shape separate processing\_valid”, etc.

When processing Dxf files, the system treats the action of tool lifting as the separate mark for the adjacent shapes. If there is no tool lifting, the system will consider only one shape is being processed. If tool lifting occurs, it indicates the processing of a complete shape is finished. For example, process several circles adjacent to each other. The depth of each circle is 10mm, and each feed depth of Z axis is 2mm. If parameter 5004 is set as true, machine tool will process the current circle 5 times, then uplift the tool, and then go to process the next circle. If it is set as false,

Parameter	Meaning	Setting Range
		machine tool will process the current circle once, then lift its tool, and then go to process the other circles. After all the circles are processed once, this process will be re-executed 4 times to finish processing all the shapes.

◆ Translation Parameters of ENG File

Parameter	Meaning	Setting Range	
5007	Select tool for ENG	If this parameter is set as true, opening an Eng file will eject a dialog box asking you to select a tool (the tool specified in the Eng file instead of the system default tool) for processing based on the processing program.	False: Not use True: Use
5008	Select tool for ENG	Only available for ENG5.50 and 5.53.	False: Not use True: Use
5009	Tool change prompt	If it is set as true, when tool change command is encountered, machine tool will suspend processing and uplift its Z axis, and prompt bar in the system will prompt tool change. At this time, you can perform the operation of tool change. If it is set as false, when tool change command is encountered, machine tool will not suspend processing, but the prompt bar in the system will still prompt tool change.	False: Invalid True: Valid
5010	Tool lifting height	It sets the tool lifting height of Z axis during rapid traverse of machine tool when an ENG file is being processed.	0~100000 (mm)
5011	Retract amount	It indicates the retract value after feed each time in manner of high-speed reciprocating chip removal for deep hole drilling.	0~100000 (mm)
5012	Cycle times of ENG processing	It sets the cycle times to process an Eng file.	/
5013	Deep hole machining manner	It sets the manner for processing deep holes.	0: Reciprocating chip removal 1: High-speed reciprocating chip removal
Translation parameters of ENG file are applied to translation for ENG files, including "Tool lifting height", "Tool change prompt", etc.			

◆ Translation Parameters of PLT File

Parameter		Meaning	Setting Range
5014	Tool lifting height	It sets the tool lifting height during rapid traverse.	0~100000 (mm)
5015	Plt unit	Normally, 1plt=40.195mm, which can be magnified or reduced by setting this parameter.	0~100000 (mm)
5016	Tool step	To process the workpiece adequately, tool spacing set needs to make the parts between the adjacent tool paths overlapped based on the tool diameter. Tool step here refers to the tool spacing in PLT file machining.	0~100000 (mm)
5017	Machining depth	It specifies the machining depth for 2D files.	/

PLT file translation parameters are applied to translation of PLT files. PLT is a format of 2D machining files defined by an American company Hewlett Packard (HP), usually used in embossment and advertising carving, including such parameters as “retract”, “PLT units”, “tool offset” and “cutting depth”. At the same time, PLT is a kind of unit. Normally, 1plt=40.195mm, which can be magnified or reduced by setting the parameter 5015.

## 3.14 Handwheel Operation

### 3.14.1 Handwheel Mode

The system supports three operation modes: auto mode, reference point mode and manual mode, and the manual mode is further subdivided into jog, stepping and handwheel. You can select handwheel mode by pressing “Handwheel” button on the operation panel.

In handwheel mode, you can configure a handwheel to control the machine tool. As shown in Fig. 3-50, select the motion axis by rotating “Axis selection button”, select handwheel override gear by rotating “Gear selection button”, and control the selected axis running at the selected handwheel override gear by rotating “Handwheel control rotation disk”. Handwheel override gear regulates the pulse equivalent sent to the machine tool from the system according to the each case turning of handwheel, and the displacement (linear displacement or rotation angle) of moving parts of machine tool can be calculated based on the pulse equivalent.



Fig. 3-50 Handwheel

◆ Related parameters

Parameter		Meaning	Setting Range
3013	Handwheel Direction	It sets the relationship between the rotating direction of the control rotation disk and feeding direction of the axis.	1: same direction -1: opposite direction
3014	Exact HW Pulse Count	When the parameter is enabled, machine will move by the distance specified by the handwheel. When it is not enabled, machine will move only when the handwheel disk is being rotated.	Yes: execute No: not execute
3015	Handwheel Acceleration	It sets the axial acceleration when the motion of axis is controlled by handwheel. (a smaller value of the parameter will get more smoother motion)	0~100000

When parameter 3014 is set to “Yes”, if the handwheel is being rotated too fast, machine may move even if handwheel rotating stops. That is because the driver will receive all pulses sent by the handwheel. When it is set to “No”, the system is more sensitive to and be more responsive to the handwheel actions, however, if the handwheel is being rotated too fast, it may result in difference between machine actual moving distance and the nominal distance specified by the handwheel.

## 3.14.2 Handwheel Guide

NK260 system supports handwheel guide.

Handwheel guide refers to a way of operation that the automatic execution speed of machining program is manually controlled during auto processing so as to guard against such problem as “tool damage” and dangers caused by wrongly loaded program or inappropriate tool path.

Fig. 3-51 is the software interface of handwheel guide, in which press F1 [HW Guide] button to activate handwheel guide. After machining starts, the system will execute the processing program with clockwise turning of handwheel and stop processing with the stop of handwheel. Processing speed varies with the handwheel turning speed.



Fig. 3-51 Handwheel Lead Interface

## 3.15 System Management

### 3.15.1 System Info

As shown in Fig. 3-52, view the related information (including CNC software information and CNC hardware information) of NcStudio in [System Info (C)] screen of [System] function section. Pressing letter key C will enter [System Info] function screen.




Fig. 3-52 System Info Screen

## 3.15.2 Network Connection

NK260 supports network connection. For details, refer to section 3.16.

## 3.15.3 Language

Press F3 under [System Info] sub-function screen of [System] function section to switch between languages. To validate the language switching, it is necessary to reboot the system.

## 3.15.4 Register

In [System Info] screen of [System] function section, “registration code” can be used to register the system and limit the system service time. Registration code is generated by registration code maker. Its generation steps are:

- 1) Learn the info of board card no. in [System Info (C)] of [System]. See Fig. 3-52.
- 2) Double click the registration code maker “GetRegCode.exe”, and then enter the password “ncstudio” (revisable) in the dialog box as shown in Fig. 3-53. Then press “OK”, input board card no., registered times and limited service time, and then click “Generate” to generate the new code displayed at the lower part, as shown in Fig. 3-54. If service time does not need limiting, input “-1” in the “limited time” bar to generate an unlimited code.




Fig. 3-53 Registration Code Maker-1




Fig. 3-54 Registration Code Maker-2

- 3) Press F1 [Register] in [System Info (C)] screen of [System] function section, then input the registration code generated in the second step into the pop-up dialog, and then click "OK".
- 4) The system prompts "register successfully".



- 1) The ID of NK260 varies with the change of registration times, reflected by the last three figures of serial number. When registration times is "0", the last three figures are "000"; when "1", the last three figures are "001".
- 2) ID (registered times) must be entered.

## 3.16 Network Connection and Share

To enable network connection function of NK260, the computer and NK260 should be connected in the same local area network via a network cable, ensuring the computer able to ping with NK260.

### 3.16.1 IP Setup

After opening NK260, set IP address to establish a network connection channel between the computer and NK260, requiring the computer in the same subnet with NK260. For instance, if the subnet mask is 255.255.255.0, 192.168.1.0 ~ 192.168.1.255 are in the same subnet.

#### 3.16.1.1 Direct Connection or Switch Connection

##### 1) NK260 IP Setup

Click the letter key C to enter [System Info(C)] screen, as shown in Fig. 3-55.






Fig. 3-55 System Information

Clicking “Net Info” will eject a dialog as shown below.



Fig. 3-56 System Info Screen- Net Info

Clicking “IP set” will eject a dialog requiring input of password, as shown in Fig. 3-57.




Fig. 3-57 System Info screen- Password Input

After password is entered correctly, IP setup page will be accessed, as shown in Fig. 3-58.




Fig. 3-58 IP Setup Page- Obtain IP Address Automatically

Pressing the letter key S will select “Set IP address Manually”, as shown in Fig. 3-59.




Fig. 3-59 IP Setup Page- Set IP Address Manually

Enter the following three address types in Fig. 3-59.

- IP address: 192.168.1.188 (the settings of the first three groups should be the same as those of the computer.)
- Subnet mask: 255.255.255.0 (the same as that of the computer)
- Default gateway: 192.168.1.1 (the same as that of the computer)

After the setting IP address, press “Enter” to confirm modification. The net info is as shown in Fig. 3-60. (For the first time setting, it is necessary to power off and to restart NK260.)




Fig. 3-60 System Info Screen- New Net Info

**◆ PC IP Setup**

Find “internet Protocol (TCP/IP) in Fig. 3-61, and then double click it to enter Fig. 3-62. Take “Use the following IP address” as an example.

- IP address: 192.168.1.189
- Subnet mask: 255.255.255.0
- Default gateway: 192.168.1.1 (The first three groups should be the same as those of IP address.)




Fig. 3-61 Local Area Connection-Properties




Fig. 3-62 PC IP Setup

### 3.16.1.2 Router Connection

Router connection is available after the router opens DHCP function to enable obtaining IP address automatically. Otherwise, only direct connection or switch connection is available as described in 3.16.1.1.

Press the letter key L to select “obtain IP address automatically, as shown in Fig. 3-63.




Fig. 3-63 Obtain IP Address Automatically

The system will then obtain an IP address automatically. For the first time setting, power off and restart are required.

In addition, setting IP address manually is also available. (The method is the same as that of direct connection.)

- IP address: 192.168.1.182 (The settings of the first three groups should be the same as those of the router gateway.)
- Subnet mask: 255.255.255.0
- Default gateway: 192.168.1.1 (The settings of the first three groups should be the same as those of IP address.)

PC IP and NK260 IP must be in the same subnet, which can be completed via manual setting or via automatic obtaining.

**3.16.1.3 Multiple NK260 Connection**

If there are multiple NK260, the IP address of each of them should not be the same. If the same, manually reset the IP address (the first three groups should be the same). MAC address of each of them should not be the same, either. If the same, modify them per the following steps:

- 1) Enter [System Info(C)] screen, as shown in Fig. 3-55;
- 2) Click “Net Info” to display network info, as shown in Fig. 3-56;
- 3) Click “ModDevice” to access the password input interface, as shown in Fig. 3-64.




Fig. 3-64 Device Info Modification- Password Input

- 4) Enter the password to access the device info modification interface, as shown in Fig. 3-65.




Fig. 3-65 Device Info Modification Interface

- 5) The name of device can be changed to WinCE01, WinCE02, WinCE03.....
- 6) Device MAC can be changed to any hexadecimal data.

### 3.16.2 Connection Verification Setup

After IP setup complete, click “Start” → “Run...” on the computer, and then enter cmd in the run dialog to access command line prompt dialog, and then enter “ping IP address”, for example, ping 192.168.1.182, to check whether the computer can ping with NK260. If pinged, the result is as shown in Fig. 3-66.




Fig. 3-66 Check Network Connection—Successful




Fig. 3-67 Check Network Connection—Failed

If failed, check whether physical connection is normal, and whether the settings above-mentioned are right.

### 3.16.3 NK260 Network Files Management by PC via FTP

Entering “Ftp://192.168.1.188” in the address bar of resource management will open NK260 network files, and FTP operations like upload, download and rename can be realized.




Fig. 3-68NK260 Network Files Managed by PC via FTP

### 3.16.4 NK260 Network Files Management by PC via Network Sharing

Click “Start” → “Run...” on the computer, and then enter “\\192.168.1.188” in the run dialog, and then press “Enter” to access NK260 network sharing interface, in which “Sharedocs” is the NK260 network folder. After opening it by double click, you can transfer files to NK260, or administrate the existing files, like edit, delete, and copy, as convenient as administrating local files.




Fig. 3-69 NK260 Network Files Management by PC via Network Sharing- 1




Fig. 3-70 NK260 Network Files Management by PC via Network Sharing- 2

The above-mentioned steps realize NK260 network files management by PC. The change of network files can also be observed in [Program] → [Local Program(A)]. Pressing “Shift + Backspace” will refresh the files in the list. The network files are marked with “Net” behind, as shown in Fig. 3-71.

Test.nc	1	2036-11-3	18:47	
M99.nc	1	2037-2-6	12:9	
M30.nc	1	2037-2-6	12:19	
ic.nc	29	2036-11-13	8:20	Net
public.nc	29	2036-11-13	7:31	Net
02.nc	29	2013-8-28	2:28	Net

Fig. 3-71 Network Files

## 3.17 Auxiliary Function

### 3.17.1 Start Line (Selective Processing)

This function is used to select desired program blocks for execution.

In [Coor-Auto] of [State] function section under Auto mode, press F2 [Start Line] to eject a “Start Line” screen, as shown in Fig. 3-72.




Fig. 3-72 Selective Machining

You can process the specified program segment to be executed by entering its start and end line number. With this function, you can process any segment freely.

### 3.17.2 Breakpoint Resume

Press [Breakpoint Resume] button on the operation panel to select this function, and then the system will continue processing from the last stop line number.

If power failure or emergency stop occurs during processing, and you are sure about the accuracy of the workpiece coordinates, they can select this function to make the machine tool rapidly move to the breakpoint for continues processing, which can save them processing time.

### 3.17.3 Parameter Auto Backup

The system holds the function of parameter auto backup. If you forget to save the set parameters, they can switch to this screen, in which parameters from the ex-factory date to system last shutdown can be restored.

[Parameter Backup (B)] sub-function screen under [Parameter] function section is as shown in Fig. 3-73: in this screen, press “↑” and “↓” direction keys to select an effective backup parameter, and then press F1 and F7 to restore or delete the selected backup parameter. By pressing F2 and F3 respectively, the selected backup parameter can be exported to the USB device or the parameter in the USB device can be imported to the system.




Fig. 3-73 Parameter Auto Backup

### 3.17.4 User Code Input

[User Code Input (C)] screen under [Advanced] function section is as shown in Fig. 3-74.






Fig. 3-74 User Code Input Screen

On the upper part of the screen, mechanical coordinates and workpiece coordinates of each axis are displayed, while on the lower part, there are 7 items of user command box, in which you can input commands and execute them.

Move the identification bar to the command to be edited or executed by pressing “↑” and “↓” direction keys, input a new instruction in the pop-up input box by pressing “Insert” key, and execute the selected instruction by pressing “Enter” key.

Pressing F1~ F7 can select and execute the corresponding user command.

### 3.17.5 Coordinate Backup

[Coordinate Backup (C)] screen under [Parameter] function section is as shown in Fig. 3-75.




Fig. 3-75 Coordinate Backup Interface

F1 “Save” can be pressed to save the current workpiece offset. After loading a machining file into the system, you can press “↑” and “↓” to select the desired workpiece offset, and then press F2 “Recover” to load the selected offset into the current WCS. See Fig. 3-76.




Fig. 3-76 Restore Workpiece Offset

After “是(Y)” (是 means Yes) is selected in Fig. 3-76, a new dialog will pop up asking whether to modify Z-axis offset, as shown in Fig. 3-77. You can select “是(Y)” if you want to restore Z-axis offset, too. Otherwise, offset of all other axes will be restored, except for Z-axis.




Fig. 3-77 Whether to Change Z-axis Workpiece Offset

## 3.18 Tool Magazine

### 3.18.1 Auto Tool Change of Linear Tool Magazine

Linear tool magazine stores tools in the form of array. For example, if a customer has 12 tools, he can select a 1-line 12-row tool magazine, or a 2-line 6-row tool magazine, etc. To realize auto tool change, our programming is done according to the related information provided by you in advance (realized in public.dat). The system offers multi-tool coordinate positions, which will not be listed here.

See Fig. 3-78 for the process of auto tool change for linear tool magazine (taking multi-workpiece and

a tool magazine parallel to X axis as an example).




Fig. 3-78 Process of Auto Tool Change for Linear Tool Magazine

### 3.18.2 Auto Tool Change of Circular Tool Magazine

When machine tool is with function of circular tool magazine and auto tool change is needed during file machining, the process of auto tool change is as follows:




Fig. 3-79 Process of Auto Tool Change for Circular Tool Magazine



Since mechanical configuration of tool magazine varies, the process mentioned above is just applied to the general situation. In case of any difference, please turn to manufacturer to make corresponding adjustment based on actual situation.

### 3.18.3 Related Parameters

Parameter		Meaning	Setting Range
2010	Positive Tool Change Travel Limit (X)	The machine coordinates of X/Y/Z of the upper limit of the tool change travel range.	Negative Travel Limit ~ 67108.864 (mm)
2011	Positive Tool Change Travel Limit (Y)		
2012	Positive Tool Change Travel Limit (Z)		
2013	Negative Tool Change Travel Limit (X)	The machine coordinates of X/Y/Z of the lower limit of the tool change travel range.	-67108.864 ~ Positive Travel Limit (mm)
2014	Negative Tool Change Travel Limit (Y)		
2015	Negative Tool Change Travel Limit (Z)		
4502	Tool magazine capacity	The largest tool number that can be saved in the tool magazine. To set the corresponding tool coordinate, the system needs rebooting after tool magazine capacity modification.	1~20
4503	Loaded tool No.	Tool No. being used	1~ Tool magazine capacity
4504	Currently Tool Mag. No.	The current tool No. indexed on the tool magazine.	1~ Tool magazine capacity
4505	Tool change prompt	Whether the system will suspend and prompt tool change when tool change command is encountered	False: Invalid True: Valid
4506	Automatic Tool Meas. After Tool Change	Whether to conduct tool measurement automatically after tool changed or not.	True: Measure False: Not measure

Parameter		Meaning	Setting Range
4507	T0 Treatment Mode	0: Disable T0; 1: Discharge loaded tool to magazine and keep empty; 2: Set initial tool No. from 0	0; 1; 2
4508	Upper Position in Tool Change	The Z axis upper position in tool change.	-(mm)
4509	Lower Position in Tool Change	The Z axis lower position in tool change.	-(mm)
4510	Position when Tool Change (X)	It specifies the spindle position when tool is changing.	-(mm)
4511	Position when Tool Change (Y)		-(mm)
4512	Ahead Position in Tool Change (X)	It specifies the position where the tool slows down its speed before entering into the tool magazine.	-(mm)
4513	Ahead Position in Tool Change (Y)		-(mm)
4514	Ahead Position in Tool Change (Z)		-(mm)
4515	Rapid Traverse Speed in Tool Change	The rapid traversing speed of the spindle in tool change.	0.001~ Max Axial Velocity (mm/min)
4516	Z Axis Speed in Tool Change	The default speed used by Z axis from the upper position to the lower position in tool change.	0.001~Rapid Traverse Speed in Tool Change (mm/min)
4517	XY Speed when Tool In/Out Mag.	The speed of X and Y axes when the tool is moving into/out of the tool magazine.	0.001~Rapid Traverse Speed in Tool Change (mm/min)
4518	Delay for Tool Change	The time delayed	0~600000(ms)
4519	Return Prior Position after Tool Change	Whether the spindle returns to the previous position after tool change.	True: Valid; False: Invalid
Under "Compensation (=) Screen	X offset	When mobile calibration is executed and tool length is set, the system will save the tool offset into these parameters.	None
	Y offset		None
	Z offset		None
Z-axis offset is tool offset, and the system will save the too offset value to parameter "Z offset" after F4 [Set Tool Length] and F5 [Mobile Cali] are pressed under [Tool Cali] sub-menu.			

# 4 Maintenance

---

<b>4.1</b>	<b>Operating System Maintenance .....</b>	<b>96</b>
4.1.1	Software Update .....	96
4.1.2	Mirror Image Update.....	98
4.1.3	System “Eboot” Interface.....	98
4.1.4	System Update Interface .....	100
<b>4.2</b>	<b>Warning Information.....</b>	<b>101</b>
<b>4.3</b>	<b>Common Troubleshooting .....</b>	<b>103</b>
4.3.1	What should you do if the spindle does not rotate?.....	103
4.3.2	What should you do if an axis does not move? .....	103
4.3.3	What should you do if servo motor Z brake can’t be opened? .....	103
4.3.4	What should you do if machine tool returns to the machine origin abnormally? .....	104
4.3.5	What should you do if the machine tool motions upward after arriving at the position of tool presetter during calibration? .....	104

## 4.1 Operating System Maintenance

When you get NK260 integrated system, the system has already been well installed and can be used directly. In case of failure, you can restore it to leaving factory state by system recovery.

When the system is damaged and cannot be booted, it is time to update system, namely update the mirror image of the system. If the system can be booted, you only need to upgrade or re-install the software.

### 4.1.1 Software Update

If the system can be booted, please upgrade or re-install the software as following steps:

- 1) Insert the USB flash disk with the latest version of the software, whose file name extension is *.weihong*, into NK260 integrated CNC system.
- 2) Re-power on NK260 and simultaneously press G key on the operational panel several times. It jumps to a software update interface as shown in Fig. 4-1, displaying that USB device identification is going on.




Fig. 4-1 Software Update Interface

- 3) After USB device identification succeeds, press F6 “System” button to open dialog box named “Update software”, as shown in Fig. 4-2. Press arrow key “↑” or “↓” to select the target software application.






Fig. 4-2 Software Update Dialog Box

- 4) With target software selected, press “Enter” for confirmation and software upgrading starts. The progressing interface is as shown below.




Fig. 4-3 Software Updating Process

- 5) Software update completes. The new software will be accessed automatically.



When previous software can be launched normally, you can upgrade the software as follows:

Launch the previous software normally, and insert the USB flash disk with the latest version of the software into NK260 system.

Access [System info] interface under [System] function area, and press F2 button to open the “Update software” interface (as Fig. 4-1).

## 4.1.2 Mirror Image Update

- 1) If the system is damaged and cannot be booted, you need to update the mirror image as following steps:
- 2) Insert the USB flash disk into NK260. The flash disk should contain the latest version of system mirror image whose file name is *NK260\_NK\_RX.X.X.nb0* and the latest version of software with file name extension *.weihong*.
- 3) Power on NK260 while pressing M key on the operational panel until entering system “Eboot” interface. Please refer to section 4.1.3 below for more details about system “Eboot”.
- 4) As shown in Fig. 4-4 below, press T key to choose mirror image update. It starts updating and the whole process lasts for about 3 minutes.
- 5) After the system mirror image update is completed successfully, the system begins to identify the USB device. When USB device identification succeeds, it will jump to “Update Software” interface (Fig. 4-1) automatically.
- 6) Press F6 to initiate the software update, the following steps are the same as steps in section 4.1.1.



- 1) When the system mirror image is updated, the software should be updated as well. Therefore, the latest version of the mirror image file (named as *NK260\_NK\_RX.X.X.nb0*) and the software application (with file name extension *.weihong*) must be stored under the root directory of the USB flash disk or NK260 file folder.
- 2) When upgrading or installing the software, the file name extension of the software must be *.weihong*, otherwise, it cannot be identified.

Please note that the above two points are based on the condition that the version of the mirror image file is R4.0.3 (or “Boot” version V1.1.6 and higher) and higher. If the version of the image file is V3.9 (or “Boot” version V1.0 and lower) and lower, software application with 5 file folders (namely *CHN*, *Config*, *ENG*, *Font*, *NewNK200*) and mirror image file (with file name extension *.nk.nb0*), INSTEAD OF the *.weihong* formatted software or mirror image file named as *NK260\_NK\_RX.X.X.nb0*, must be stored under the root directory of the USB flash disk.

## 4.1.3 System “Eboot” Interface

Press M key during power on the system until entering system “Eboot” interface, as shown below. It includes seven types of update.




Fig. 4-4 Eboot Interface

**◆ F) Update FPGA**

Update the FPGA.

**◆ T) Update OS**

The “Update OS” here refers to system mirror image update in nature. When the system is damaged and cannot be booted, select this item.

**◆ S) Update BOOT**

Update BOOT.

**◆ G) Update LOGO**

Update the LOGO picture in the interface when the system initiates.

**◆ R) Read Version Number**

Read and obtain the versions of current BOOT and OS (operating system).

**◆ X) Register Reset**

Clear and empty the contents which have been written into the system registry, and restore to the default leaving factory state.

Taking system IP address as an example, you can set IP address in [System info] interface for network connection, and this address will be then written into the system registry. If “Register Reset” item is executed, the IP address will be reset to default value 0.0.0.0.

**◆ P) System Repair**

When the system can be booted while the software cannot be launched normally, you can select this item. The system will execute self-recovery. After system recovery, software can be launched after power on.

## 4.1.4 System Update Interface

Considering “Software Update” interface has been referred to in both mirror image update and software update, here is the brief introduction to the interface, as shown below.




Fig. 4-5 Software Update Interface

### ◆ Public File

Update the public files, namely, use the new PUBLIC file saved in file folders CHN\files or ENG\files under the root directory of the USB disk or NK260 file folder.

### ◆ Backup

Export the parameters backup files and the software to the folder NK260Backup under the root directory of the flash disk or NK260 file folder. Please note that the name of the backup software contains time information, therefore, for the same software, it may have several software applications with different parameters backup.

### ◆ Restore

With the button pressed, the software applications which have been backed up will be shown in the list. You can select one of them to restore.

### ◆ Delete Parameters

When upgrading software or installing new software, parameter settings of the last version can be deleted with this item selected. If you need to save previous parameter settings, neglect it.

### ◆ Config

Use the new configuration file, namely, *Config* file.







### ◆ System

To upgrade the software. That is, to upgrade or install a new version of software. Please note that only software application with file name extension *.weihong* can be identified.

## ◆ Run Old

To launch the previous system.

## 4.2 Warning Information

Type	Warning Content	Cause	Solution
 Warning message			
 Limit alarm	Positive (negative) limit of X (YZ) axis	The polarity of X-axis positive limit port is wrong.	Enter [Port] function screen under [System], and modify the port polarity (refer to section 3.5).
		X-axis runs into limit switch directly during motion.	Manually move X-axis away from limit switch.
		There is an error in limit switch itself.	Check if limit switch works normally.
 Servo alarm	Servo alarm of X (YZ) axis	The polarity of X-axis servo alarm port is wrong.	Enter [Port] function screen under [System], and modify the port polarity (refer to section 3.5).
		There is an error in X-axis servo driver itself.	Check if X-axis servo driver works normally.
 E-stop alarm	E-stop button is pressed.	The polarity of E-stop port is wrong.	Enter [Port] function screen under [System], and modify the port polarity (refer to section 3.5).
		The E-stop button is pressed.	Turn the E-stop button clockwise to make it bounced.
 Oil level alarm	Oil level alarm	The polarity of oil level alarm port is wrong.	Enter [Port] function screen under [System], and modify the port polarity (see section 3.5).
		When the oil level line in the oil pump is below a certain value, a signal will be sent to the system to give an alarm.	Check if the oil mass is too small in the oil pump.
 Spindle alarm	Spindle alarm	The polarity of spindle alarm port is wrong.	Enter [Port] function screen under [System], and modify the port polarity (see section 3.5).
		There is an error in inverter.	Find the reason based on the

Type	Warning Content	Cause	Solution
			alarm type of inverter.
Error message			
Related operations of backing to machine origin	The system has not returned to the machine origin, failed to execute the operation!	The system has not returned to machine origin. Whether the system has to back to machine origin is decide by parameter 1065 "Back to reference point before mach". If it is set as "true", it is a must to back to the machine origin before machining.	Use this function after executing backing to machine origin.
Related errors of state	The system is busy, this operation can't be executed.	Some illegal operations are performed under machining state.	Stop machining, and execute some operations under idle state.
	Please exit from simulation mode in the status page before changing the state!	It is possible that some illegal operations are performed under simulation mode, like modifying a parameter or pressing some shortcut keys.	Stop simulation and execute some operations under idle state.
	Please switch to Auto mode first.	Perform some operations only available under Auto mode in Manual and Reference Point modes, like pressing "Program Start" under Manual mode.	Switch to Auto mode and then perform the corresponding operation.
	Breakpoint resuming can't be executed under current state.	"Breakpoint Resuming" button is pressed in the process of machining.	Breakpoint resuming can be performed to continue machining in case of power failure, manually pressing "Program Stop" button, and E-stop in machining.
File error	There is no file loaded in the current parser.	Start file machining with no file loaded in the system.	Load a machining file before start machining.
	Failed to read the machining file, and check if the path of this file is changed.	The file loaded originally is deleted.	It is necessary to re-load the machining file.

## 4.3 Common Troubleshooting

### 4.3.1 What should you do if the spindle does not rotate?

- 1) Start spindle, and check if the spindle start indicator lamp on the terminal board is on.
- 2) If it lights, measure if the SPIN port is conducted and the analog voltage output is normal between SVC and GND with a multimeter. If it is conducted and normal, check whether the parameter setting of inverter is right, whether the spindle and inverter have been damaged, or whether the wiring of the spindle and inverter is correct.
- 3) If not, close the host machine and power off machine tool, and then re-plug the connection cable of terminal board. If it still does not light, please change another terminal board or NK260 host.

### 4.3.2 What should you do if an axis does not move?

- 1) Check if there is output (in green) for “x servo enable” signal of output port in [Port] screen under [System]. If there is output, the software works normally. Check if the port polarity (it should be NO “N”) is set correctly.
- 2) Check if the parameter setting of servo driver is correct (like setting control mode as position control, selecting pulse input port for Panasonic driver, etc.).
- 3) Check if the servo cable of this axis is well contacted at the joint with system host machine and servo driver.
- 4) Check if something is wrong with servo driver, motor cable, servo cable or control system (e.g. exchange servo cable and servo driver with those of other axes working normally).

### 4.3.3 What should you do if servo motor Z brake can't be opened?

Start the system and power on machine tool (eliminating system alarm signal), and see if the brake output indicator lamp on the terminal board turns light.

- 1) If light, test whether there is 24V voltage between brake output ports (BRAKE-COM) with a multimeter. If there is 24V voltage, check whether the wiring of motor brake cable is correct. The motor brake cable should be connected to brake output port on terminal board directly.
- 2) If not, directly conduct the brake input ports (K+, K-) on terminal board with a conducting wire. If light at this time, check whether the servo driver is enabled, the parameter setting related to brake output of servo driver is right, and brake output line of driver is correctly wired to terminal board (black line is wired to K-, and only K+ is connected to with only one line); if still not light, please change the terminal board.

#### 4.3.4 What should you do if machine tool returns to the machine origin abnormally?

- Limit alarm or servo driver alarm occurs during backing to the machine origin.
- 1) Check if the software can receive the REF. point signal of this axis. The method is: trigger the home switch, and then see if the color of the dot before the “x machine origin” changes from red to green in [Port] screen under [System]. If there is no color change, it indicates the software can't receive the REF. point signal, needing to check if there is an error in the home switch (if the terminal board is EX9A4, the switch type should be NPN; if EX6A4, the switch type should be PNP) or in the wiring of home switch. To see if the system failure occurs, make the REF. point signal on the terminal board and COM port into conduction directly with a conducting wire, and then check whether the color of the dot before “x machine origin” changes in [Port] screen.
- 2) Check whether the position of home switch is appropriate to avoid the following three situations: the distance between home switch and limit switch is too small; the home switch is installed behind the limit switch; or the position of home switch is out of the mechanical stroke of machine tool.
- When backing to the machine origin, the machine tool motions towards a certain direction at a relatively low speed (ten percent of the speed of coarse positioning) until limit is triggered.

See if the polarity of “x machine origin” input port is correct in [Port] screen under [System]. When this home switch is triggered, i.e. there is signal input, the color of the dot should be green. Otherwise, it is red.

- A certain axis moves a very long distance or keeps moving at a rather low speed towards the reverse direction after coarse positioning during backing to machine origin.

The cause of the above phenomenon is that the system can't detect the encoder REF. point signal of this axis.

- 1) Move the machine manually and check if the encoder zero signal in [Port] activated;
- 2) See if the servo cable of this axis is well contacted at the joints with NK260 host and servo driver;
- 3) Check if there is an error in the driver, motor, encoder cable, servo cable or the CNCI system (e.g. exchange servo cable and servo driver with those of other axes able to return to the machine origin normally in turn).

#### 4.3.5 What should you do if the machine tool motions upward after arriving at the position of tool presetter during calibration?

View and tell whether the polarity of “tool presetter signal” is right in [Port] screen under [System]. The color of the dot before the “tool presetter” signal is red when the system does not receive tool presetter signal.



# 5 Driver

<b>5.1</b>	<b>Driver Parameters .....</b>	<b>107</b>
5.1.1	Parameter Setting of WISE Servo Driver .....	107
5.1.2	Parameter Setting of YASKAWA $\Sigma-II$ Servo Driver .....	108
5.1.3	Parameter Setting of YASKAWA $\Sigma-V/\Sigma-7$ Servo Driver.....	110
5.1.4	Parameter Setting of PANASONIC MINAS A4 Servo Driver .....	111
5.1.5	Parameter Setting of PANASONIC MINAS A5 Servo Driver .....	111
5.1.6	Parameter Setting of MITSUBISHI MR-JE Servo Driver.....	113
5.1.7	Parameter Setting of MITSUBISHI MR-E Servo Driver .....	114
5.1.8	Parameter Setting of DELTA ASDA-A Servo Driver.....	115
5.1.9	Parameter Setting of DELTA ASDA-B Servo Driver .....	116
5.1.10	Parameter Setting of DELTA ASDA-A2 Servo Driver.....	118
5.1.11	Parameter Setting of DELTA ASDA-B2 Servo Driver.....	119
5.1.12	Parameter Setting of SANYO PY Servo Driver .....	121
5.1.13	Parameter Setting of SANYO R Servo Driver .....	123
5.1.14	Parameter Setting of SANYO Q Servo Driver.....	123
5.1.15	Parameter Setting of KT270 Servo Driver.....	124
5.1.16	Parameter Setting of FUJI FALDIC- $\beta$ Servo Driver.....	126
5.1.17	Parameter Setting of STONE GS Servo Driver .....	127
5.1.18	Parameter Setting of TECO TSDA Servo Driver.....	128
<b>5.2</b>	<b>Wiring Diagram of NK260 Host and Differential Input Stepping Driver .....</b>	<b>130</b>
<b>5.3</b>	<b>Wiring Diagram of Driver and Terminal Board.....</b>	<b>130</b>
5.3.1	Wiring Diagram of WISE Servo Driver .....	131
5.3.2	Wiring Diagram of YASKAWA AC Servo Driver .....	132
5.3.3	Wiring Diagram of PANASONIC AC Servo Driver .....	133
5.3.4	Wiring Diagram of MITSUBISHI MR-JE Servo Driver .....	134
5.3.5	Wiring Diagram of MITSUBISHI MR-E Servo Driver.....	135
5.3.6	Wiring Diagram of DELTA Servo Driver.....	135
5.3.7	Wiring Diagram of FUJI Servo Driver.....	138
5.3.8	Wiring Diagram of HITACHI Servo Driver .....	138
5.3.9	Wiring Diagram of SANYO PY Servo Driver .....	139
5.3.10	Wiring Diagram of SANYO R Servo Driver .....	140

5.3.11	Wiring Diagram of KT270 Servo Driver .....	140
5.3.12	Wiring Diagram of STONE GS Servo Driver .....	141
5.3.13	Wiring Diagram of TECO TSDA Servo Driver .....	142
5.3.14	Wiring Diagram of TECO ESDA Servo Driver .....	143




## 5.1 Driver Parameters

Parameters listed in this chapter can make the machine work normally without ensuring machining results. Relevant parameters need adjusting according to the specific machine type.

### 5.1.1 Parameter Setting of WISE Servo Driver

Para. No.	Function	Value	Description
Pr528	LED initial status	6	Monitor if the number of sent and received pulses is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
Pr008	Command pulse No. per motor circle	0	When it is set to "0", parameters Pr009 and Pr010 are valid.
Pr009	1 <sup>st</sup> numerator of command pulse frequency division/multiplication	Need calculation 0~2 <sup>30</sup>	Typical value: pitch 5 mm, encoder resolution 10000, deceleration ratio 1:1, pulse equivalent 0.001 mm: Pr009=10000 Pr010=pitch 5mm/ pulse equivalent 0.001mm=5000 Pr009/Pr010=10000/5000=2/1
Pr010	Denominator of command pulse frequency division/multiplication	Need calculation 0~2 <sup>30</sup>	
Pr100	1st position loop gain	480 (default)	Unit: 0.1/s. Set it according to the actual situation.
Pr101	1st velocity loop gain	270 (default)	Unit: 0.1Hz. Set it according to the actual situation.
Pr102	1st velocity loop integrated time constant	210 (default)	Unit: 0.1ms. Set it according to the actual situation.
<p>When the value of Pr008 is not "0", it should be calculated according to the following formula:</p> $\text{Command Pulse No. per Motor Circle} = \frac{\text{Screw Pitch}}{\text{Pulse Equivalent} \times \text{Mechanical Deceleration Ratio}} = \frac{5\text{mm}}{0.001\text{mm/p}} = 5000$ <p>That is to say, when screw pitch is 5mm and pulse equivalent is 0.001, the value of Pr008 is 5000.</p>			

◆ Attached list: the relationship among parameters Pr0008, Pr0009 and Pr010

Pr008	Pr009	Pr010	Description
0~2 <sup>20</sup>	— (no influence)	— (no influence)	 <p>As shown above, the process is undergone in terms of the setting value of Pr008, not affected by the settings of Pr009 and Pr010.</p>
0	0	0~2 <sup>30</sup>	 <p>When the values of Pr008 and Pr009 are both set to “0”, as shown above, the process is undergone in terms of the setting value of Pr010.</p>
	0~2 <sup>30</sup>	0~2 <sup>30</sup>	 <p>When the value of Pr008 is “0”, but the value of Pr009 is not “0”, as shown above, the process is undergone in terms of the setting values of Pr009 and Pr010.</p>

### 5.1.2 Parameter Setting of YASKAWA Σ-II Servo Driver

Para. No.	Function	Value	Description
Fn010	Set password (to prevent arbitrary modification to parameters)	0000	Set [0000]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] permitted; Set [0001]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] prohibited.
Un00C	Surveillance mode	LXXXX (Hexadecimal system)	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
Pn000	Direction selection Control mode selection	0010	Bit 0: Set 0, “CCW” rotation is forward rotation (viewed from the load end of screw ball); Set 1, the rotation direction of the motor is reversed. Bit 1: Set 1, position control mode (calculate pulse instruction all the time).
Pn200	Select pulse	0005	Bit 0: Set 5, select the instruction input mode as

Para. No.	Function	Value	Description		
	instruction mode		"pulse + direction", negative logic. Bit3: Set 0, input differential signal into filter.		
Pn50A	Selection function	8100	Bit 1: Set 0, Servo ON /S-ON, input from the 40th pin; Set 7, Servo ON all the time. Bit 3: Set 8, forward rotation not used and signal input (P-OT) prohibited.		
Pn50B	Selection function	6548	Bit 0: Set 8, reverse rotation not used and signal input (N-OT) prohibited.		
Pn50F	Selection function	0300	Set it when servo motor with brakes. Bit 2: Set 3, brake interlock signal "/BK" is output from CN1-29, CN1-30 to control 24V relay for brake.		
Pn50E	Selection function	0211	Set it when servo motor with brakes. To avoid of CN1-29 and CN1-30 being used for other function and leading to brake ineffective, "3" is not allowed to appear in the 4 digits.		
Pn506	Servo off, time delay of brake when motor stops	Depended	Set it when motor with brakes. Default setting is "0", setting unit is 10ms.		
Pn201	Encoder cycle-divided ratio (Pulse output No. per motor cycle after cycle-divided)	See right-side	Gain Encoder	Type	Pulse No. per Motor Circle (PPR)
				A	13bit 2048
				B	16bit 16384
				C	17bit 32768
Pn202	Electronic gear ratio (numerator)	Need Calculation	Pn202 = pulse No. of each encoder circle $\times$ 4 $\times$ mechanical deceleration ratio. Pn203 = (screw pitch/ pulse equivalent). Typical value: pitch 5mm, encoder 17-bit, coaxial connection between motor and screw, pulse equivalent 0.001mm, Pn202 = 16384; Pn203 = 625.		
Pn203	Electronic gear ratio (denominator)	Need Calculation	Pitch 5mm, encoder 17-bit, coaxial connection between motor and screw, pulse equivalent 0.0005mm, Pn202 = 8192; Pn203 = 625.		

### 5.1.3 Parameter Setting of YASKAWA $\Sigma$ -V/ $\Sigma$ -7 Servo Driver

Para. No.	Function	Value	Description
Fn010	Parameter input prohibition setting	0000	Set [0000]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] permitted. Set [0001]: modification to user parameters [PnXXX] and part of auxiliary function parameters [FnXXX] prohibited.
Pn000	Function selection basic switch 0	0010	Bit 0: Set 0, positive rotation at positive rotation command; Bit 1: Set 1, position control mode (pulse sequence command)
Pn200	Format selection switch of position control command	0005	Bit 0: Set 5, select the instruction mode as "pulse + direction", negative logic.
Pn50A	Input signal selection 1	8100	Bit 1: Set 0, Servo ON /S-ON, input from the 40 <sup>th</sup> pin; Set 7, Servo ON all the time. Bit 3: Set 8, positive rotation not used and signal input (P-OT) prohibited.
Pn50B	Input signal selection 2	6548	Bit 0: Set 8, negative rotation not used and signal input (N-OT) prohibited.
Pn50F	Output signal selection 2	0300	Set it when servo motor with brakes. Bit 2: Set 3, brake interlock signal "/BK" is output from CN1-29, CN1-30 to control 24V relay used for brake.
Pn50E	Output signal selection 1	0211	Set it when servo motor with brakes. To avoid of CN1-29 and CN1-30 being used for other function and leading to brake ineffective, 3 is not allowed to appear in the 4 digits.
Pn506	Brake instruction-servo OFF time delay	Depended	Set it when motor with brakes Default setting is "0", setting unit is ms.
Pn20E	Electronic gear ratio (numerator)	Need Calculation	$\frac{Pn20E}{Pn210} = \frac{\text{Encoder Resolution} \times \text{Pulse Equivalent} \times \text{Deceleration Ratio}}{\text{Screw Pitch}}$ For example, screw pitch 5mm, 20-bit encoder, coupling direct drag, pulse equivalent 0.001mm,
Pn210	Electronic gear ratio (denominator)	Need Calculation	$\frac{Pn20E}{Pn210} = \frac{2^{20} \times 0.001}{5} = \frac{1048576}{5000} = \frac{131072}{625}$ When screw pitch is 10mm, $\frac{PN20E}{PN210} = \frac{1048576}{10000} = \frac{65536}{625}$ For a rotary axis with 13-bit encoder and deceleration ratio as 60,

Para. No.	Function	Value	Description
			$\frac{Pn20E}{Pn210} = \frac{2^{13} \times 0.001 \times 60}{360} = \frac{8192}{6000} = \frac{512}{375}$

### 5.1.4 Parameter Setting of PANASONIC MINAS A4 Servo Driver



Para. No.	Function	Value	Description
Pr01	LED initial status	12	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
Pr02	Select control mode	0	0: position mode 1: velocity mode 2: torque mode
Pr40	Selection of command pulse input	1	1: input by differential exclusive circuit
Pr42	Select command pulse input mode	3	Set command pulse input mode: pulse + direction, negative logic
Pr48	1st numerator of command pulse frequency multiplication	Need calculation Range: 1~10000	Typical value: pitch 5 mm, encoder resolution 10000, shaft coupling direct drag, pulse equivalent 0.001 mm: Pr48= 10000 Pr4B= pitch 5mm / pulse equivalent 0.001mm=5000 Pr48/Pr4B=10000/5000=2/1
Pr4B	Denominator of command pulse frequency multiplication	Need calculation Range: 1~10000	

### 5.1.5 Parameter Setting of PANASONIC MINAS A5 Servo Driver

Para. No.	Function	Value	Description
Pr5.28	LED initial status	6	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control

Para. No.	Function	Value	Description
			card is detected by pulse inspection in order to determine whether there is electrical interference.
Pr0.01	Select control mode	0	0: position mode 1: velocity mode 2: torque mode
Pr0.05	Selection of command pulse input	XX	0: Photo-coupler input (PULS1, PULS2, SIGN1, SIGN2) 1: Exclusive input for line driver (PULSH1, PULSH2, SIGNH1, SIGNH2) Note: generally, "1" is selected for this parameter.
Pr0.07	Command pulse input mode setup	3	Set command pulse input mode: pulse + direction, negative logic.
Pr0.08	Command pulse counts per one motor revolution	0	When it is set as "0", parameters Pr0.09 and Pr0.10 are valid.
Pr0.09	1st numerator of command pulse frequency multiplication	Need calculation Range: 0~2 <sup>30</sup>	Typical value: pitch 5 mm, encoder resolution 10000, shaft coupling direct drag, pulse equivalent 0.001 mm: Pr0.09 = 10000 Pr0.10 = pitch 5mm / pulse equivalent 0.001mm = 5000 Pr0.09/Pr0.10 = 10000/5000 = 2/1
Pr0.10	Denominator of command pulse frequency multiplication	Need calculation Range: 0~2 <sup>30</sup>	
<p>When the value of Pr0.08 is not "0", it can be calculated in terms of the following formula:</p> $\text{Command Pulse No. per Motor Circle} = \frac{\text{Screw Pitch}}{\text{Pulse Equivalent} \times \text{Mechanical Deceleration Ratio}} = \frac{5\text{mm}}{0.001\text{mm/p}} = 5000$ <p>When screw pitch is 5mm and pulse equivalent 0.001mm/p, the value of Pr0.08 is "5000".</p>			

◆ Attached List: the relationship among parameters Pr0.08, Pr0.09 and Pr0.10.

Pr0.08	Pr0.09	Pr0.10	Description
0~2 <sup>20</sup>	— (no influence)	— (no influence)	 <p>The process shown above is undergone in terms of the setting value of Pr0.08, not affected by the settings of Pr0.09 and Pr0.10.</p>
0	0	0~2 <sup>30</sup>	 <p>When the values of Pr0.08 and Pr0.09 are both set as "0", as</p>



Pr0.08	Pr0.09	Pr0.10	Description
			shown above, the process is undergone in terms of the setting value of Pr0.10.
	0~2 <sup>30</sup>	0~2 <sup>30</sup>	<div style="text-align: center;"> <pre> graph LR     A[Command Pulse Input] --&gt; B[Setting Value of Pr0.09 / Setting Value of Pr0.10]     B --&gt; C[Position Command]                     </pre> </div> <p>When the value of Pr0.08 is “0”, but the value of Pr0.09 is not “0”, as shown above, the process is underdone in terms of the setting values of Pr0.09 and Pr0.10.</p>

### 5.1.6 Parameter Setting of MITSUBISHI MR-JE Servo Driver

Para. No.	Code	Function	Value	description
PA01	*STY	Operation mode	XXX0	__ _x: select position control mode.
PD24	MBR	Output assignation to CN1-23 pin	XX05	__ xx: select MBR (electromagnetic brake interlock).
PA06	CMX	Electronic gear numerator	Need calculation	CMX/CDV=command unit × servo motor resolution × mechanical deceleration ratio / pitch of screw. E.G., pitch 5 mm, encoder resolution 10000, deceleration ratio 1:1, pulse equivalent 0.001 mm, CMX/CDV=10000×0.001/5 = 2/1; When pulse equivalent = 0.0005mm, CMX/CDV = 1/1. Electronic gear ratio range: 1/50 ~ 500
PA07	CDV	Electronic gear denominator	Need calculation	
PC36	*DMD	Status display selection	00XX	__ _xx: status display selection at power-on. This is used to select a status display shown at power-on. 00: cumulative feedback pulses 01: servo motor speed 02: droop pulses 03: cumulative command pulses 04: command pulse frequency
PA13	*PLSS	Command pulse input form	0011	Set command pulse input form: pulse train+ sign, negative logic.
PD03	*DI1L	Input assignation to CN1-15 pin	XX02	__ _xx: select SON under position control mode.

## 5.1.7 Parameter Setting of MITSUBISHI MR-E Servo Driver

Para. No.	Code	Function	Value	Description
0	*STY	Control mode selection and regenerative fittings	X0X0	Bit 0: set 0: select position control mode. Bit 1, select motor series: 0: HC-KFE; 1:HC-SFE; Bit 3, select regenerative apparatus, set 0: not use. Bit 4, select motor power.
1	MBR	Function selection 1	001X	Bit 0: input signal filter. If external input signal causes chattering due to noises, etc., input filter is used to suppress it. Bit 1: CN1-12 function selection, set "1": electromagnetic brake interlock (MBR); set "0": zero speed detection signal.
3	CMX	Electronic gear numerator	Need calculation	CMX/CDV=command unit × servo motor resolution × mechanical deceleration ratio / screw pitch. E.G, pitch 5 mm, encoder resolution 10000, shaft coupling direct drag, pulse equivalent 0.001 mm, CMX/CDV=10000×0.001/5 = 2/1; When pulse equivalent = 0.0005mm, CMX/CDV = 1/1. Electronic gear ratio range: 1/50 ~ 500
4	CDV	Electronic gear denominator	Need calculation	
18	*DMD	Status display selection	00XX	3: cumulative command pulses E: load inertia When the parameter is set [3], monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection to determine if there is electrical interference.
21	*OP3	Function selection 3 (command pulse format selection)	0001	Set pulse command input form: pulse train+ sign, negative logic
41	*DIA	Signal input SON-ON, LSP-ON and LSN-ON automatically selection	0110	Bit 0: Servo-ON selection. [0]: servo on by external input; [1]: servo on all the time inside. Bit 1: last signal of positive rotation range (LSP): [1]: auto servo on inside, without external wiring. Bit 3: last signal of negative rotation range (LSN): [1]: auto servo on inside and no need of external wiring.

## 5.1.8 Parameter Setting of DELTA ASDA-A Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection to determine if there is electrical interference.
P1-00	External pulse input type	ZYX	002	X=2: pulse + direction; Z=0: positive logic
P1-01	Control mode setup	ZYX1X0	0000	Z=0: during control mode switching, DIO is maintaining the set value. Since switching control mode is not used, Z=0 Y=0: forward rotation (CCW) (in terms of load); Y=1: the rotation direction is reversed. X1X0=00: position control mode
P1-32	Motor stop mode selection	YX	00	Y=0: when there is no servo enabled, motor dynamic brake occurs; Y=1: motor is free. X=0: motor stops instantly, X=1: motor stops with deceleration.
P1-44	Electronic Gear Ratio (Numerator)(N1)	1~32767	Need calculation	N1/M= encoder pulses × 4× pulse equivalent× mechanical deceleration ratio/ pitch
P1-45	Electronic Gear Ratio (Denominator) (M)	1~32767	Need calculation	Representative value: encoder pulses=2500, pitch=5mm, pulse equivalent=0.001, deceleration ratio=1, calculation as below: N1/M= 2500×4×0.001/5 = 2 / 1, N1=2, M=1; When the multi-electronic gear ratio is not used, P2-60~ P2-62 are not required.
P2-10	Digital Input Pin DI1	X2X1X0	101	X1X0=01: digital input (DI1=SON) corresponds to 9th pin of CN1. X2 = 1: set DI1 input as NO (normally open) a-contact point.
P2-15	Digital Input pin DI6	X2X1X0	100	Default factory setting of DI6 and DI7 are NC (normally closed) limit signal input pins;

Para. No.	Function	Format & Range	Value	Description
P2-16	Digital Input Pin DI7	X2X1X0	100	driver can't run without being connected to pin 32 and pin 31 of CN1. X2=1: set DI6 and DI7 inputs as NO (normally open) a-contact points; X1X0=00, limit signal input of the driver is not used.
P2-17	Function setting for digital input pin DI8	X2X1X0	100	External EMG stop input is not used.
P2-21	Function setting for digital output pin DO4	X2X1X0	108	DO4 corresponds to pin 1 & pin 26, used as clamping-position brake signal of Z-axis; X2=1: set DO4 output as NO (normally open) a-contact point; X2=0: set DO4 output as NC (normally closed) b-contact point; X1X0=08: set pin 1 and pin 26 as BK+ and BK- respectively.
P2-22	Function setting for digital output pin DO5	X2X1X0	007	DO5 corresponds to pin 28 & pin 27, used as servo alarm signal. X2=0: set DO5 output as NC (normally closed) b-contact point. X1X0=07: set pin 28 and pin 27 as ALRM+ and ALRM- respectively.
P2-51	Servo ON (SON) setup		0	0: Servo ON must be triggered by numerical input signal. 1: when servo is powered, if there is no alarm signal, servo will be automatically on. Set 1 when there is no SON signal wire.

### 5.1.9 Parameter Setting of DELTA ASDA-B Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.

Para. No.	Function	Format & Range	Value	Description
P1-00	External pulse train input type	ZYX	002	X=2: pulse + direction; Z=0: positive logic
P1-01	Set control mode	YX1X0	000	Y=0: forward rotation (CCW) (from the view of load) Y=1: the rotation direction is reversed. X1X0=00: position control mode
P1-32	Motor stop mode	YX	00	Y=0: when there is no servo enabled, motor dynamic brake occurs; Y=1: motor is free. X=0: motor stops instantly; X=1: motor stops with deceleration.
P1-44	Electronic Gear Ratio (Numerator) (N1)	1~32767	Need calculation	N1/M= mechanical deceleration ratio × 4 × encoder pulses × pulse equivalent / pitch. Representative value: encoder pulses=2500, pitch =5mm, pulse equivalent=0.001 mm/p, deceleration ratio = 1, calculation as below: N1 / M = 2500×4×0.001/5 = 2/1, N1=2, M=1; When the multi-electronic gear ratio is not used, P2-60 ~P2-62 are not required.
P1-45	Electronic Gear Ratio (Denominator) (M)	1~32767	Need calculation	
P2-10	Digital Input Pin 1 (DI1)	X2X1X0	101	X1X0=01: digital input (DI1 = SON) corresponds to 17th pin of CN1. X2=1: set DI1 input as NO (normally open) a-contact point.
P2-15	Function setting for digital input pin DI6	X2X1X0	100	Default factory setting of DI6 is NC (normally closed) limit signal input; driver can't run without being connected to pin 32 and pin 31 of CN1. X2=1: set DI6 input as NO a-contact point. X1X0=00, limit input of driver is not used.
P2-18	Function setting for digital output pin DO1	X2X1X0	108	DO1 corresponds to the 16th pin, as clamping-position brake signal of Z-axis; X2=1: set DO1 output as NO a-contact point; X2=0: set DO1 output as NC b-contact point; X1X0=08: set the 16th pin as BK+.
P2-20	Function setting for digital output pin DO3	X2X1X0	007	DO3 corresponds to pin 1, used as servo alarm signal. X2=0: set DO3 output as NC b-contact

Para. No.	Function	Format & Range	Value	Description
				point; X1X0=07: set pin 1 as ALRM+.

### 5.1.10 Parameter Setting of DELTA ASDA-A2 Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
P1-00	External pulse train input type	ZYX	002	X=2: pulse + direction; Z=0: positive logic
P1-01	Set control mode	ZYX1X0	0000	Z=0: during control mode switching, DIO is maintaining the set value. Since switching control mode is not used, Z=0; Y=0: positive rotation (CCW) (from the view of load); Y=1: negative rotation (CCW) X1X0=00: position control mode
P1-44	Electronic Gear Ratio (Numerator) (N1)	1~32767	Need calculation	$\frac{P1-44}{P1-45} = \frac{\text{Encoder Reso.} \times \text{Pulse Equiv.} \times \text{Mech. Dece. Ratio}}{\text{Screw Pitch}}$
P1-45	Electronic Gear Ratio (Denominator) (M)	1~32767	Need calculation	Assuming encoder resolution is 1280000, pitch 5mm, pulse equivalent 0.001, and non-cascade connection, then: $\frac{P1-44}{P1-45} = \frac{1280000 \times 0.001}{5} = \frac{256}{1}$ When the multi-electronic gear ratio is not used, P2-60 ~P2-62 are not required.
P2-10	Digital Input Pin 1 (DI1)	X2X1X0	101	X1X0=01: digital input (DI1 = SON) corresponds to 9th pin of CN1. X2=1: set DI1 input as NO (normally open) a-contact point.
P2-15	Function setting for digital input pin DI6	X2X1X0	100	Default factory setting of DI6 and DI7 is NC (normally closed) limit signal input; driver can't run without being connected to pin 32

Para. No.	Function	Format & Range	Value	Description
				and pin 31 of CN1. X2=1: set DI6 and DI7 input as NO a-contact points. X1X0=00, limit input of driver is not used.
P2-16	Function setting for digital input pin DI7	X2X1X0	100	
P2-17	Function setting for digital input pin DI8	X2X1X0	100	External EMG stop input is not used.
P2-21	Function setting for digital output pin DO4	X2X1X0	108	DO4 corresponds to pin 1 & pin 26, used as clamping-position brake signal of Z-axis; X2=1: set DO4 output as NO (normally open) a-contact point; X2=0: set DO4 output as NC (normally closed) b-contact point; X1X0=08: set pin 1 and pin 26 as BK+ and BK- respectively.
P2-22	Function setting for digital output pin DO5	X2X1X0	007	DO5 corresponds to pin 28 & pin 27, used as servo alarm signal. X2=0: set DO5 output as NC b-contact point. X1X0=07: set pin 28 and pin 27 as ALRM+ and ALRM- respectively.

### 5.1.11 Parameter Setting of DELTA ASDA-B2 Servo Driver

Para. No.	Function	Format & Range	Value	Description
P0-02	Driver status display		02	Monitor if the number of sent and received pulse is correct by setting this parameter. In Weihong control system, the correct quantity of pulse sent by control card is detected by pulse inspection in order to determine whether there is electrical interference.
P1-00	External pulse train input type	ZYX	002	X=2: pulse + direction; Z=1: positive logic

Para. No.	Function	Format & Range	Value	Description
P1-01	Set control mode	ZYX1X0	0000	Z=0: during control mode switching, DIO is maintaining the set value. Since switching control mode is not used, Z=0; Y=0: forward rotation (CCW) (from the view of load); Y=1: the rotation direction is reversed. X1X0=00: position control mode
P1-44	Electronic Gear Ratio (Numerator) (N1)	1~32767	Need calculation	N1/M= mechanical deceleration ratio $\times 4 \times$ encoder pulses $\times$ pulse equivalent / pitch. Representative value: encoder pulses=40000, pitch =5mm, pulse equivalent=0.001, deceleration ratio = 1, calculation as below: $N1 / M = 40000 \times 4 \times 0.001 / 5 = 32 / 1$ , N1=32, M=1; When the multi-electronic gear ratio is not used, P2-60 ~P2-62 are not required.
P1-45	Electronic Gear Ratio (Denominator) (M)	1~32767	Need calculation	
P2-10	Digital Input Pin DI1	X2X1X0	101	X1X0=01: digital input (DI1 = SON) corresponds to 9th pin of CN1. X2=1: set DI1 input as NO (normally open) a-contact point.
P2-15	Function setting for digital input pin DI6	X2X1X0	000	Default factory setting of DI6 and DI7 is NC (normally closed) limit signal input; driver can't run without being connected to pin 32 and pin 31 of CN1. X2=0: set DI6 and DI7 inputs as NC b-contact point. X1X0=00, limit input of driver is not used.
P2-16	Function setting for digital input pin DI7	X2X1X0	000	
P2-17	Function setting for digital input pin DI8	X2X1X0	000	External EMG stop input is not used.
P2-18	Function setting for digital output pin DO1	X2X1X0	108	DO1 corresponds to pin 6 & pin 7, used as clamping-position brake signal of Z-axis; X2=1: set DO1 output as NO (normally open) a-contact point; X2=0: set DO1 output as NC (normally closed) b-contact point; X1X0=08: set pin 6 and pin 7 as BK- and BK+ respectively.
P2-22	Function setting	X2X1X0	007	DO5 corresponds to pin 28 & pin 27, used



Para. No.	Function	Format & Range	Value	Description
	for digital output pin DO5			as servo alarm signal. X2=0: set DO5 output as NC b-contact point. X1X0=07: set pin 28 and pin 27 as ALRM+ and ALRM- respectively.

### 5.1.12 Parameter Setting of SANYO PY Servo Driver

Para. No.	Abbr.	Name	Standard Value	Setting Range	Unit	Remark
1-2	EGER	Electronic gear ratio	4/1	1/32767 to 32767/1		Depends on the specific encoder resolution. The formula of electronic gear ratio of servo driver is as below: Electronic gear ratio numerator =mechanical deceleration ratio × 4× pulse No. per encoder circle; Electronic gear ratio denominator = (screw pitch / pulse equivalent) E.G. In Weihong system, the default pulse equivalent is 0.001mm/p, screw pitch is 5mm, pulse number per encoder circle is 2000 shaft coupling direct drag, currently the numerator of the electronic gear ratio is 8, and the denominator is 5. (Select incremental type encoder)
1-16	MENP	Pulse amount of the motor encoder 1. Set the pulse amount of the motor encoder; 2. Standard configuration of the encoder pulse No. is as below. Incremental encoder omitting wiring: --2000P/R Absolute		500 to 65535	P/R	

Para. No.	Abbr.	Name	Standard Value	Setting Range	Unit	Remark																																				
		encoder:--2048P/R																																								
2-0	PMOD	<p>Pulse format of position command: Our system uses: direction + pulse format, the parameters are shown as following:</p> <p>PMOD: 7 6 5 4 3 2 1 0</p> <p>When bit 7=0</p> <table border="1"> <thead> <tr> <th>Bit 1</th> <th>Bit 0</th> <th>Command Pulse Input Digital Filter Min. Pulse Width</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0.8μs</td></tr> <tr><td>0</td><td>1</td><td>0.2μs</td></tr> <tr><td>1</td><td>0</td><td>0.4μs</td></tr> <tr><td>1</td><td>1</td><td>1.6μs</td></tr> </tbody> </table> <p>When bit 7=1</p> <table border="1"> <thead> <tr> <th>Bit 1</th> <th>Bit 0</th> <th>Command Pulse Input Digital Filter Min. Pulse Width</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>3.2μs</td></tr> <tr><td>0</td><td>1</td><td>0.8μs</td></tr> <tr><td>1</td><td>0</td><td>1.6μs</td></tr> <tr><td>1</td><td>1</td><td>6.4μs</td></tr> </tbody> </table> <p>Bit6 Bit5 Command Pulse Format</p> <table border="1"> <tbody> <tr><td>1</td><td>0</td><td>Direction + Pulse</td></tr> </tbody> </table> <p>Switch of Digital Filter</p> <table border="1"> <tbody> <tr><td>0</td><td>High Speed</td></tr> <tr><td>1</td><td>Low Speed (1/4)</td></tr> </tbody> </table>	Bit 1	Bit 0	Command Pulse Input Digital Filter Min. Pulse Width	0	0	0.8μs	0	1	0.2μs	1	0	0.4μs	1	1	1.6μs	Bit 1	Bit 0	Command Pulse Input Digital Filter Min. Pulse Width	0	0	3.2μs	0	1	0.8μs	1	0	1.6μs	1	1	6.4μs	1	0	Direction + Pulse	0	High Speed	1	Low Speed (1/4)			
Bit 1	Bit 0	Command Pulse Input Digital Filter Min. Pulse Width																																								
0	0	0.8μs																																								
0	1	0.2μs																																								
1	0	0.4μs																																								
1	1	1.6μs																																								
Bit 1	Bit 0	Command Pulse Input Digital Filter Min. Pulse Width																																								
0	0	3.2μs																																								
0	1	0.8μs																																								
1	0	1.6μs																																								
1	1	6.4μs																																								
1	0	Direction + Pulse																																								
0	High Speed																																									
1	Low Speed (1/4)																																									
4-3	TYPE	<p>Control mode: *Select one control mode from position, velocity, and torque modes.</p> <table border="1"> <thead> <tr> <th>Selection Item</th> <th>Content</th> </tr> </thead> <tbody> <tr><td>Position</td><td>Position control mode</td></tr> <tr><td>Velocity</td><td>Velocity control mode</td></tr> <tr><td>Torque</td><td>Torque control mode</td></tr> <tr><td>Velo ↔ Torq</td><td>Velocity ↔ Torque switch mode</td></tr> <tr><td>Posi ↔ Torq</td><td>Position ↔ Torque switch mode</td></tr> <tr><td>Posi ↔ Velo</td><td>Position ↔ Velocity switch mode</td></tr> </tbody> </table> <p>Referring to the switch type, the requisite control mode can be selected from pin 36 or 35 of the CN1. Func3, set Bit7 as 0: pin 36 is enabled. set Bit7 as 1: pin 35 is enabled. \$\$\$ : standard value varies with the reset setup (leave factory setting).</p>	Selection Item	Content	Position	Position control mode	Velocity	Velocity control mode	Torque	Torque control mode	Velo ↔ Torq	Velocity ↔ Torque switch mode	Posi ↔ Torq	Position ↔ Torque switch mode	Posi ↔ Velo	Position ↔ Velocity switch mode				<p>6 types</p> <p>Our system selects position control mode.</p>																						
Selection Item	Content																																									
Position	Position control mode																																									
Velocity	Velocity control mode																																									
Torque	Torque control mode																																									
Velo ↔ Torq	Velocity ↔ Torque switch mode																																									
Posi ↔ Torq	Position ↔ Torque switch mode																																									
Posi ↔ Velo	Position ↔ Velocity switch mode																																									

### 5.1.13 Parameter Setting of SANYO R Servo Driver

Para. No.	Parameter Name	Set Value	Remarks
Group 0, parameter setting of tuning mode			
00	Setting of tuning mode	00	Set as auto tuning mode
Group 8, setting of the control parameters			
00	Polarity of position input	00	Position command mode: positive rotation effective
11	Input command mode	02	Pulse train + negative logic, negative logic
15	Setting of electronic gear	8/5	It depends on the resolution of the specific encoder. E.G.: incremental encoder 2000, motor needs $2000 \times 4 = 8000$ pulses per circle. And pulse equivalent of Weihong control card is 0.001mm/p, it needs 1000 pulses to move 1mm along line, in other words, if the screw pitch is 5, so, to move 5mm along line needs 5000 pulses, so $F = 8000/5000 = 8/5$ .
Group 9, setting of function effective			
05	Servo ON selection	02	Select servo ON state.
02	Servo alarm elimination	10	Make the function of servo alarm effective
Setting of the system parameters			
02	Encoder selection	00	Standard incremental encoder. The parameter depends on the specific situation, what we list is only the representative one.
03	Encoder resolution	2000	500—65535, set the encoder resolution manually.
08	Control mode selection	02	Select position control mode

### 5.1.14 Parameter Setting of SANYO Q Servo Driver

Para. No.	Parameter Name	Set Value	Remarks
Group 1			
GER1	Electronic gear ratio 1	1/1	Set electronic gear ratio for position command pulse. E.G., incremental encoder 2000, motor needs $2000 \times 4 = 8000$ pulses per circle. And pulse equivalent of Weihong control card is 0.001mm/p, it needs 1000 pulses to move 1mm along line, in other words, if the screw pitch is 5, so, to move 5mm along line needs 5000 pulses, so $F = 8000/5000 = 8/5$ .

Para. No.	Parameter Name	Set Value	Remarks
GER2	Electronic gear ratio 2	1/1	This setting is the same as that of electronic gear ratio 1 and activated during electronic gear switching.
Group 4			
PA400	Command pulse selection	00H	Set position command pulse as "pulse + direction".
Group 8			
S-ON	Servo ON	02H	Select servo ON state.
AL-RST	Alarm reset	10H	Make the function of servo alarm effective
Setting of the system parameters			
01	Encoder selection	00	Standard incremental encoder. The parameter depends on the specific situation, what we list is only the representative one.
03	Incremental encoder resolution	2000	500—65535, set the encoder resolution manually.
08	Control mode selection	02	Select position control mode

### 5.1.15 Parameter Setting of KT270 Servo Driver

Para. No.	Parameter Name	Value	Description
PA4	Control mode selection	0	The control mode of the driver can be set through this parameter: 0: position control mode; 1: speed control mode; 2: trial run control mode; 3: JOG control mode.
PA12	Numerator of position command pulse ratio	2	Set the ratio of the position command pulse (electronic gear). Under position control mode, with the setting of the PA12 and PA13, it is convenient to match with pulse source of each type, which can reach your perfect control resolution (that is angle/pulse) Expression: $P \times G = N \times C \times 4$ P: pulse amount of the input command; G: electronic gear ratio, G=ratio numerator / ratio denominator. N: circle number that the motor rotates; C: each circle line number of photo electricity encoder, C of our system =2500.

Para. No.	Parameter Name	Value	Description
			<p>E.G.: input 6000 command pulses to make the servo motor rotate one circle,</p> $G = \frac{N \times C \times 4}{P} = \frac{1 \times 2500 \times 4}{6000} = \frac{5}{3}$ <p>So set PA12 as 5 and PA13 as 3. We recommend the range of electronic gear ratio as:</p> $\frac{1}{50} \leq G \leq 50$
PA13	Denominator of the position command pulse ratio	1	Refer to parameter PA12.
PA14	Input mode of the position command pulse	0	<p>Set the input mode of the position command pulse; there are following three modes can be selected by setting the parameter:</p> <p>0: pulse + symbol; 1: positive rotation pulse/ negative rotation pulse; 2: two orthogonal pulses inputs Default setting is 0: pulse + symbol, negative logic.</p>
PA20	Invalid input on the end of the stroke	1	<p>0: Valid stroke end of LSP, LSN positive rotation, negative rotation. When switch LSP is connected, driving of the positive rotation is allowed; When switch LSP is disconnected, driving of the positive rotation is prohibited (torque of the positive direction is 0). LSN is the same as LSP. If LSP and LSN are all disconnected, the abnormal alarming of driving prohibited will occur (NO.7).</p> <p>1: Invalid stroke end of LSP, LSN positive rotation, negative rotation. No matter which state of the switch LSP and LSN is in, driving of positive rotation and negative rotation are all allowed. Simultaneously, even if LSP and LSN are all disconnected, abnormal alarming of driving prohibited will not occur (NO.7).</p> <p>2: Invalid stroke end of LSP, LSN positive rotation, negative rotation, and SON is forced to be effective. (Note: SON forcedly effective is only used for motor debugging. In normal use, we suggest controlling the state of SON by input port.)</p>

Para. No.	Parameter Name	Value	Description
			3: Valid stroke end of LSP, LSN positive rotation, negative rotation. When switch LSP is connected, driving of the positive rotation is allowed; When switch LSP is disconnected, driving of the positive rotation is prohibited (the speed of positive direction is 0, but the torque is not 0). LSN is the same as LSP. When LSP and LSN are all disconnected, abnormal alarming of driving prohibited will not occur (NO.7).













### 5.1.16 Parameter Setting of FUJI FALDIC- $\beta$ Servo Driver

Para. No.	Name	Value	Description
01	Command pulse numerator $\alpha$	Need calculation 1~32767	Command pulse numerator and denominator are equal to those of the electronic gear ratio. $\alpha / \beta = \text{encoder resolution} \times \text{pulse equivalent} \times \text{mechanical deceleration ratio} / \text{screw pitch}$ . Typical value: encoder resolution 65536, pitch 5mm, pulse equivalent 0.001, mechanical deceleration ratio 1, $\alpha / \beta = 65536 \times 0.001 / 5 = 8192 / 625$ , So $\alpha = 8192$ , $\beta = 625$ .
02	Command pulse denominator $\beta$	Need calculation 1~32767	
03	Pulse string input form	0	Set the input mode of pulse string as: instruction + symbol, that is 'pulse + direction'.
04	Direction of rotation switch	0 or 1	Set 0: Positive direction: Forward rotation (CCW) Set 1: Positive direction: Reverse rotation (CW)
10	CONT1 signal distribution	1	CONT1 is distributed as RUN (i.e. SON); if not distributed, CONT1 will be auto ON if there is no alarming when powered.
11	CONT2 signal distribution	2	CONT2 is distributed as RST (i.e. servo alarming clearance CLR). When 12, 13, 14 are 0, that is CONT3, CONT4 and CONT5 can't be distributed as OT over-travel or EMG (external emergency stop).
15	OUT1 signal distribution	1	Set 1, OUT1 is distributed as a-contact point of alarming output; Set 2, OUT1 is distributed as b-contact point of alarming detection.
27	Parameter	0 or 1	Set 0, write-enable.

Para. No.	Name	Value	Description
	write-protection		Set 1, write-protected.
74	CONT always ON 1	1	Initial value: 0. when set "1", servo is activated (RUN).

### 5.1.17 Parameter Setting of STONE GS Servo Driver

Para. No.	Para. Name	Value	Description																							
F0f	Electronic gear ratio numerator	2	Electronic gear ratio of position mode: $4 \times \text{pulse frequency fed back by servo encoder} = \text{command pulse frequency} \times F0f / F10$ ; value of $F0f / F10$ must be within $1/100 \sim 100$ . (calculation with pitch 10mm)																							
F10	Electronic gear ratio denominator	1																								
F00	Control mode selection	2	<p>0: External speed running mode; make sure the value and direction of motor speed according to the external analog <math>-10V \sim +10V</math> signal of CN2-16, 17;</p> <p>1: Internal speed running mode; make sure the value and direction of motor speed according to the setting of parameter F33, F35, F37, F39 and the port status of CN2-9, CN2-25;</p> <p>2: Position pulse running mode; accept the input of external position pulse and direction level signal;</p> <p>3: Jog mode; make sure the motor speed in terms of parameter setting of F3b, and control the rotation direction by the direction keystroke ▼ and ▲;</p> <p>4: Torque mode; make sure the value and direction of motor torque according to the external analog <math>-10V \sim +10V</math> signal of CN2-43, 1;</p> <p>5~10: Mixed mode; select mode according to the port input status of CN2-24:</p> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th rowspan="2">F00 Value</th> <th colspan="2">CN2-24 Interface Status</th> </tr> <tr> <th>OFF (Mode One)</th> <th>ON (Mode Two)</th> </tr> </thead> <tbody> <tr> <td>5</td> <td>Position Pulse Mode</td> <td>External Speed Running Mode</td> </tr> <tr> <td>6</td> <td>Position Pulse Mode</td> <td>Internal Speed Running Mode</td> </tr> <tr> <td>7</td> <td>Position Pulse Mode</td> <td>Torque Mode</td> </tr> <tr> <td>8</td> <td>Internal Speed Running Mode</td> <td>External Speed Running Mode</td> </tr> <tr> <td>9</td> <td>Internal Speed Running Mode</td> <td>Torque Mode</td> </tr> <tr> <td>10</td> <td>External Speed Running Mode</td> <td>Torque Mode</td> </tr> </tbody> </table>	F00 Value	CN2-24 Interface Status		OFF (Mode One)	ON (Mode Two)	5	Position Pulse Mode	External Speed Running Mode	6	Position Pulse Mode	Internal Speed Running Mode	7	Position Pulse Mode	Torque Mode	8	Internal Speed Running Mode	External Speed Running Mode	9	Internal Speed Running Mode	Torque Mode	10	External Speed Running Mode	Torque Mode
F00 Value	CN2-24 Interface Status																									
	OFF (Mode One)	ON (Mode Two)																								
5	Position Pulse Mode	External Speed Running Mode																								
6	Position Pulse Mode	Internal Speed Running Mode																								
7	Position Pulse Mode	Torque Mode																								
8	Internal Speed Running Mode	External Speed Running Mode																								
9	Internal Speed Running Mode	Torque Mode																								
10	External Speed Running Mode	Torque Mode																								

Para. No.	Para. Name	Value	Description
F2e	Pulse input mode selection	2	<p>Command pulse string mode selection of position mode:</p> <p>1 - Single pulse train positive logic            Pulse <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             Direction <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p> <p>2 - Single pulse train negative logic            Pulse <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             Direction <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p> <p>3 - Double pulse train positive logic            CCW <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             CW <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p> <p>4 - Double pulse train negative logic            CCW <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             CW <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p> <p>5 - Orthogonal pulse positive logic            Phase A <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             Phase B <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p> <p>6 - Orthogonal pulse negative logic            Phase A <span style="border: 1px solid black; padding: 2px;">12</span> <span style="border: 1px solid black; padding: 2px;">27</span>             Phase B <span style="border: 1px solid black; padding: 2px;">13</span> <span style="border: 1px solid black; padding: 2px;">28</span> </p>

### 5.1.18 Parameter Setting of TECO TSDA Servo Driver

Para. No.	Function	Value	Description		
Pn010-1	Set control mode	1	Value	Control mode	
			0	CN1 Pin12 open circuit	CN1 Pin12 closed circuit
			1	Speed control	Speed control
			2	Position control	Position control
			3	Torque control	Torque control
			4	Speed control	Speed control
			5	Position control	Position control
Pn010-2	Set the pulse input format under position control mode	0	Value	The format of pulse input	
			0	Pulse + direction	
			1	Dipulse	
Pn010-3	Set rotation direction of motor	1	Value	Function	
			0	Input positive order, motor rotates CCW.	
			1	Input positive order, motor rotates CW.	
Pn021	Electronic gear ratio numerator	Need calculation	The input pulse amount will be multiplied with this number before output. Ratio range of parameter 21 to 22: 1/127 < parameter 21 / parameter 22 < 127		
Pn022	Electronic gear ratio denominator		The input pulse amount will be multiplied with this number before output. Ratio range of parameter 21 to 22:		



Para. No.	Function	Value	Description	
			1/127 < parameter 21/ parameter 22 < 127	
Pn011-4	Set the value of Pin20 of CN1	1	Value	Function
			0	Output of "0" speed signal
			1	Output of brake signal
Pn013-1	Set the maximum pulse frequency received by the driver under position control mode	7	It can correct the phenomenon of unauthorized over-travel. Received frequency is divided into 8 segments from 500Kpps to 200Kpps. "0" indicates 500Kpps while "7" 200Kpps.	



For the parameter setting of driver of various brands, refer to the driver manual of specific brand.

## 5.2 Wiring Diagram of NK260 Host and Differential Input Stepping Driver






Fig. 5-1 Wiring Diagram of NK260 Host and Differential Input Stepping Driver



## 5.3 Wiring Diagram of Driver and Terminal Board

Wiring diagrams in this part are the wiring diagrams of control system-axes control-driver motion. When you want to use one axis of the control system to control the motion of two drivers, the wiring diagram is as shown in Figure 2 in section 5.3.2 and Figure 4 in section 5.3.6 (take YASKAWA driver and DELTA driver as an example; for YASKAWA server, its alarm signal wiring is NC type, while for DELTA server, its alarm signal wiring is NO type).


### 5.3.1 Wiring Diagram of WISE Servo Driver





### 5.3.2 Wiring Diagram of YASKAWA AC Servo Driver




### 5.3.3 Wiring Diagram of PANASONIC AC Servo Driver



### 5.3.4 Wiring Diagram of MITSUBISHI MR-JE Servo Driver





### 5.3.5 Wiring Diagram of MITSUBISHI MR-E Servo Driver





### 5.3.6 Wiring Diagram of DELTA Servo Driver


DELTA ASDA-A, ASDA-A2, ASDA-AB share the same wire. Among them, ASDA-A2 and ASDA-AB have the same wiring pin while ASDA-A has the contrary pulse pin, with PULSE 41, /PULSE 43. For detailed parameter setting, refer to section 5.1.8 and section 5.1.10.









### 5.3.7 Wiring Diagram of FUJI Servo Driver




### 5.3.8 Wiring Diagram of HITACHI Servo Driver




### 5.3.9 Wiring Diagram of SANYO PY Servo Driver




### 5.3.10 Wiring Diagram of SANYO R Servo Driver




### 5.3.11 Wiring Diagram of KT270 Servo Driver




### 5.3.12 Wiring Diagram of STONE GS Servo Driver



### 5.3.13 Wiring Diagram of TECO TSDA Servo Driver



### 5.3.14 Wiring Diagram of TECO ESDA Servo Driver



# 6 Parameter Overview

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
<b>1. Op-Param (Operation Parameter)</b>					
1001	Rapid JOG Feedrate	JOG Feedrate ~ MAX Axial Velocity (mm/min)	3500	Immediately	3.9.3
1002	JOG Feedrate	0 ~ Rapid JOG Feedrate (mm/min)	1500	Immediately	3.9.3
1003	Default Rapid Traverse Feedrate (G00)	Default Feedrate ~ MAX Axial Velocity (mm/min)	3500	Immediately	3.9.2
1004	Default Feedrate (GXX)	Z-axis Approach Speed ~ MAX Axial Velocity (mm/min)	3000	Immediately	3.9.1
3001	Safety Height	0~5000 (mm)	10	Immediately	-
3002	Axis Acceleration	0.001~100000 (mm/ s <sup>2</sup> )	800	Immediately	3.9.3
3003	Dry Run Acceleration	0.001~100000 (mm/ s <sup>2</sup> )	800	Immediately	3.9.3
3004	Max Turning Acceleration	0.001~100000 (mm/ s <sup>2</sup> )	3000	Immediately	3.9.3
3005	Delay for Acute Angle	-(ms)	0	Immediately	-
3006	Startup Speed	0~Z-axis Approach Speed (mm/ min)	0	Immediately	3.9.3
3007	Max Machining Speed	Machining speed ~ MAX Axial Velocity (mm/min)	10000	Immediately	-
3008	ToolMeas. TraverseSpeed To Fixed Tool Sensor	1 ~ Rapid JOG Feedrate (mm/min)	400	Immediately	3.6.3
3009	Fixed Tool Sensor Thickness	0~100 (mm)	10	Immediately	3.6.2/ 3.6.3
3010	Tool Sensor Fixed Position (MCS) (X)	Negative Travel Limit (MCS) ~ Positive Travel Limit (MCS)	0	Immediately	3.6.3
3011	Tool Sensor Fixed Position (MCS) (Y)			Immediately	3.6.3
3012	Tool Sensor Fixed Position (MCS) (Z)			-1	Immediately
3013	Handwheel Direction	-1: Opposed to axis output direction 1: Same as axis output direction	1	After restart	3.14.1
3014	Precise Pulse Counting	True: Valid	False	After restart	3.14.1



Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
		False: Invalid			
3015	Handwheel Acceleration	0~100000	200	After restart	3.14.1
3016	Traverse Feedrate Override Fixed 100%	True: Use False: Not use	True	After restart	3.9.3
3017	JOG Feedrate Override Fixed 100%	True: Valid False: Invalid	True	After restart	3.9.3
3018	Ignore Feedrate Code (F)	True: Valid False: Invalid	True	Immediately	3.9.3
3019	Ignore Spindle Speed Code (S)	True: Valid False: Invalid	True	Immediately	3.9.3
3020	Back to REF Required before Cycle Start	True: Valid False: Invalid	True	Immediately	3.3.2
3021	Cancel REF Sign on Estop	True: Valid False: Invalid	True	Immediately	3.3.2
3022	Servo Disable on Estop	True: Valid False: Invalid	False	Immediately	-
3023	MAX Angle for Fast Corner Velocity	0~180.001 (deg)	120	Immediately	-
3024	Path Preprocess Mode	0: No treatment 1: Tolerance treatment 2: Smooth treatment	0	Immediately	-
3025	Path Preprocess Accuracy	0~0.5001 (mm)	0.1	Immediately	-
3026	Look Ahead Distance for Velocity	0~0.05 (mm)	0	Immediately	-
3027	Look Ahead Path Segments	1~100	50	Immediately	-
3028	Path Interpolation Algorithm Options	0: Velocity triangle; 1: Velocity S-type	1	Immediately	3.9.3
3029	Z Down Feedrate Limitation Options	0: No limitation 1: Z Down Feedrate Limitation valid with only Z-axis downward movement 2: Z Down Feedrate Limitation valid with Z-axis downward movement included	0	Immediately	3.9.3
3030	Z Down Feedrate Limitation	0.0 ~ MAX Axial Velocity (Z) (mm/ min)	300	Immediately	3.9.3

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
3031	Z-axis Deceleration Distance	0~999 (mm)	10	Immediately	3.9.3
3032	Z-axis Approach Speed	0~ Default Feedrate (mm/min)	600	Immediately	3.9.3
3033	MAX Axial Velocity (X)	6~15000 (mm/min)	15000	After restart	3.9.3
3034	MAX Axial Velocity (Y)	6~15000 (mm/min)	15000	After restart	3.9.3
3035	MAX Axial Velocity (Z)	Z Down Feedrate Limitation ~ 15000 (mm/min)	15000	After restart	3.9.3
3036	Enable Arc Velocity Limitation	True: Valid False: Invalid	True	Immediately	3.9.3
3037	MAX Velocity of Ref. Circle	- (mm/min)	3500	Immediately	3.9.3
3038	Enable Short Line Velocity Smoothing	True: Valid False: Invalid	True	Immediately	3.9.3
3039	Short Line Ref. Length in Velocity Smoothing	0.001~100000 (mm)	2	Immediately	3.9.3
3040	Path Smoothing Time	0~2 (sec)	0	Immediately	-
3041	Arc Radius Tolerance	0~999 (mm)	2	Immediately	-
3042	Enable Arc IJK incremental mode	True: Valid False: Invalid	True	Immediately	-
3043	Spindle Off on Pause	True: Valid False: Invalid	True	After restart	3.4
3044	Spindle Off when Cycle Stop	True: Valid False: Invalid	True	After restart	3.4
3045	Is open coolant while starting	True: Valid False: Invalid	False	After restart	-
3046	Is close coolant while stopping	True: Valid False: Invalid	False	After restart	-
3047	Spindle Off when Cycle Completed	True: Stop False: Not stop	True	Immediately	3.4
3048	MAX Spindle Speed	10000~999999 (r/min)	24000	After restart	3.4
3049	Delay for Spindle On/Off	0~60000 (ms)	5000	Immediately	3.4
3050	Spindle Speed when Centering	0~ MAX Spindle Speed (r/min)	500	Immediately	-
3051	Spindle Action Options when Cycle Completed	0: Not move 1: Back to fixed point 2: Back to workpiece origin	0	Immediately	3.4
3052	Notification Options	0: Red light not on	0	Immediately	-

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
	when Cycle Completed	1: Red light on for 3s 2: Red light not off until there is mouse or keyboard input			
3053	Fixed Point Position in MCS (X)	-67108.864~67108.864 (mm)	0	Immediately	3.4
3054	Fixed Point Position in MCS (Y)		0	Immediately	3.4
3055	Fixed Point Position in MCS (Z)		-1	Immediately	3.4
3056	Retract Distance for Code G73_G83	0~9999.9 (mm)	0	Immediately	-
<p>This parameter is used under both G73 command and G83 command with different meanings. When G73 command is used, this parameter means the uplifting distance after each peck. When G83 is executed, this parameter refers to the distance between the feed plane where the cutter changes from G00 to Gxx and the previous peck depth. See <i>Programming Manual</i> for the details of G73 and G83.</p>					
3057	Z Axis Lift Distance on Pause	0~10000 (mm)	10	After restart	-
2116	Enable Auto Lubricate	True: Valid False: Invalid	False	Immediately	-
2117	Lubricate Interval	0~34560000(sec)	18000	Immediately	-
2118	Lubricate Duration	0~34560000(sec)	5	Immediately	-
2119	Cycle Interval	0~3600000(sec)	0	Immediately	-
<b>2. Axis Param</b>					
2001	Pulse Equivalent (X)	0.0001~999 (mm/p)	0.001	After restart	3.2.2
2002	Pulse Equivalent (Y)		0.001	After restart	3.2.2
2003	Pulse Equivalent (Z)		0.001	After restart	3.2.2
2004	Positive Travel Limit in X-axis (MCS)	Negative Travel Limit ~ 67108.864 (mm)	400	After restart	3.2.3
2005	Positive Travel Limit in Y-axis (MCS)		400	After restart	3.2.3
2006	Positive Travel Limit in Z-axis (MCS)		0	After restart	3.2.3
2007	Negative Travel Limit in X-axis (MCS)	-67108.864 ~ Positive Travel Limit (mm)	0	After restart	3.2.3
2008	Negative Travel Limit in Y-axis (MCS)		0	After restart	3.2.3
2009	Negative Travel Limit in Z-axis (MCS)		-100	After restart	3.2.3

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
2010	Positive Tool Change Travel Limit (X)	Negative Travel Limit ~ 67108.864 (mm)	400	After restart	-
2011	Positive Tool Change Travel Limit (Y)			After restart	-
2012	Positive Tool Change Travel Limit (Z)		0	After restart	-
2013	Negative Tool Change Travel Limit (X)	-67108.864 ~ Positive Travel Limit (mm)	0	After restart	-
2014	Negative Tool Change Travel Limit (Y)			After restart	-
2015	Negative Tool Change Travel Limit (Z)		-100	After restart	-
2016	Deceleration Time to Soft Limit	0.01~10 (sec)	0.5	After restart	-
2017	X-axis Direction	-1 1	1	After restart	3.2.1
2018	Y-axis Direction		1	After restart	3.2.1
2019	Z-axis Direction		1	After restart	3.2.1
2120	Enable Y-axis as Rotary Axis	True: Valid False: Invalid	False	After restart	-
2121	Programming Unit Options for Rotary Y-axis	True: mm False: degree	False	After restart	-
2122	Pulse Equivalent for Rotary Y-axis	0 ~100000 (deg/p)	0.006	After restart	-
2123	Rotary Workpiece Diameter	0~100000 (mm)	20	After restart	-
2124	Rotary Y-axis Startup Speed	0~100000(rad/s)	0.2909	Immediately	-
2125	Rotary Y-axis Acceleration	0.001 ~100000 (mm/ s <sup>2</sup> )	6.9813	Immediately	-
2126	Rotary Y-axis MAX Feedrate	0.06~250 (Related to pulse equivalent setting) (r/min)	30	Immediately	-
4101	Screw Error Compensation Options	0: No compensation 1: Unilateral 2: Bilateral	0	After restart	3.11.1
4102	Enable Backlash Compensation	True: Valid False: Invalid	False	After restart	3.11.1
4103	Enable Quadrant Compensation	True: Valid False: Invalid	False	After restart	3.11.3
4104	Quadrant	0~0.3015 (sec)	0	After restart	3.11.3

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
	Compensation Time				
4105	Quadrant Compensation Value	0~10 (mm)	0	After restart	3.11.3
4106	Quadrant Compensation Delay	0~10 (sec)	0	After restart	3.11.3
4107	Quadrant Compensation Intensity	0~1	0.75	After restart	3.11.3
<b>3. File Param</b>					
Dxf file translation parameters					
5001	Lift Height for DXF	0~99999 (mm)	1	Immediately	3.13.3
5002	Cutting Depth for DXF	-99999~0 (mm)	-1	Immediately	3.13.3
5003	Enable First Point as WCS Zero	True: Valid False: Invalid	True	Immediately	3.13.3
5004	Enable Single Shape Cutting	True: Valid False: Invalid	False	Immediately	3.13.3
5005	Enable Flat Bottom Cutting	True: Valid False: Invalid	False	Immediately	3.13.3
5006	Force Metric Unit in DXF	True: Metric False: Inch	False	Immediately	3.13.3
Eng file translation parameters					
5007	Enable ENG Tool Selection	True: Valid False: Invalid	True	Immediately	3.13.3
5008	Enable ENG Tool No. Change	True: Valid False: Invalid	True	Immediately	3.13.3
5009	Tool Change Notification	True: Valid False: Invalid	True	Immediately	3.13.3
5010	Lift Height for ENG	0~100000 (mm)	1	Immediately	3.13.3
5011	Retract Distance	0~100000 (mm)	1	Immediately	3.13.3
5012	Cycle Times for ENG	-	1	Immediately	3.13.3
5013	Peck Drilling Mode Options	0: Reciprocating chips removal 1: High speed reciprocating chips removal	0	Immediately	3.13.3
Plt file translation parameters					
5014	Lift Height for PLT	0~100000 (mm)	5	Immediately	3.13.3
5015	Plt Unit	0~100000 (mm)	40	Immediately	3.13.3
5016	PLT Cutter Space	0~100000 (mm)	0.025	Immediately	3.13.3
5017	Cutting Depth for PLT	-	-1	Immediately	3.13.3

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
<b>4. Origin Param</b>					
2101	REF Switch Positioning Direction (X)	-1, 1	-1	Immediately	3.3.2
2102	REF Switch Positioning Direction (Y)	-1, 1	-1	Immediately	3.3.2
2103	REF Switch Positioning Direction (Z)	-1, 1	1	Immediately	3.3.2
2104	Back Distance (X)	-	2	Immediately	3.3.2
2105	Back Distance (Y)	-	2	Immediately	3.3.2
2106	Back Distance (Z)	-	-2	Immediately	3.3.2
2107	REF Switch Positioning Speed (X)	0.001~MAX Axial Velocity (X) (mm/min)	1800	Immediately	3.3.2
2108	REF Switch Positioning Speed (Y)	0.001~MAX Axial Velocity (Y) (mm/min)	1800	Immediately	3.3.2
2109	REF Switch Positioning Speed (Z)	0.001~MAX Axial Velocity (Z) (mm/min)	1500	Immediately	3.3.2
2110	REF Encoder Positioning Speed (X)	0.001~MAX Axial Velocity (mm/min)	200	Immediately	3.3.2
2111	REF Encoder Positioning Speed (Y)		200	Immediately	3.3.2
2112	REF Encoder Positioning Speed (Z)		100	Immediately	3.3.2
2113	Pitch (X)	0.001~9999.9 (mm)	5	Immediately	3.3.2
2114	Pitch (Y)	0.001~9999.9 (mm)	5	Immediately	3.3.2
2115	Pitch (Z)	0.001~9999.9 (mm)	5	Immediately	3.3.2
<b>5. ToolPak Param</b>					
4500	Enable Cutter Compensation	True: Valid False: Invalid	False	Immediately	3.11.2
4501	Cutter Compensation Option	1: Normal type 2: Intersect type 3: Insert type	1	Immediately	3.11.2
4502	Tool Mag. Capacity	1~20	10	After restart	3.18.3
4503	Loaded Tool No.	1~ Tool Mag. Capacity	1	Immediately	3.18.3
4504	Currently Tool Mag. No.	1~ Tool Mag. Capacity	1	Immediately	3.18.3
4505	Tool Change Notification	True: Prompt False: Not prompt	False	Immediately	3.18.3
4506	Automatic Tool Meas. after Tool Change	True: Measure False: Not Measure	False	Immediately	3.18.3

Para. No.	Name	Setting Range	Default Value	When Enabled	Reference
4507	T0 Treatment Mode	0: Disable T0; 1: Discharge Loaded tool to magazine and keep empty; 2: Set initial tool No. from 0	0	After restart	3.18.3
4508	Upper Position in Tool Change	- (mm)	-1	Immediately	3.18.3
4509	Lower Position in Tool Change	- (mm)	0	Immediately	3.18.3
4510	Position when Tool Change (X)	- (mm)	0	Immediately	3.18.3
4511	Position when Tool Change (Y)	- (mm)	0	Immediately	3.18.3
4512	Ahead Position in Tool Change (X)	- (mm)	0	Immediately	3.18.3
4513	Ahead Position in Tool Change (Y)	- (mm)	0	Immediately	3.18.3
4514	Ahead Position in Tool Change (Z)	- (mm)	0	Immediately	3.18.3
4515	Rapid Traverse Speed in Tool Change	0.001~MAX Axial Velocity (mm/min)	3000	Immediately	3.18.3
4516	Z Axis Speed in Tool Change	0.001~ Rapid Traverse Speed in Tool Change (mm/min)	60	Immediately	3.18.3
4517	XY Speed when Tool In/ Out Tool Mag.	0.001~ Rapid Traverse Speed in Tool Change (mm/min)	60	Immediately	3.18.3
4518	Delay for Tool Change	0~600000 (ms)	500	Immediately	3.18.3
4519	Return Prior Position after tool change	True: Valid False: Invalid	False	Immediately	3.18.3
4520	T1 Position (X) in MCS	- (mm)	0	Immediately	-
4521	T1 Position (Y) in MCS	- (mm)	0	Immediately	-
4522	T1 Position (Z) in MCS	- (mm)	0	Immediately	-

# 7 Software License Agreement

---

**Important—Read Carefully before Using This Product:**

The term “Software Product” includes all copies of the licensed software and its documentation. This license agreement is a legal agreement between You (either an individual, a legal entity or any affiliated companies or other entities) and Weihong Electronic Technology Co., Ltd. (hereinafter referred to as Weihong Company). By installing, copying, or otherwise using the Software Product, you agree to be bound by the terms and conditions of this license. Unless otherwise stated in this agreement, you shall not use, copy, revise, rent, or transfer the Software product or any part of the Software Product for any other purposes.

**Description of Further Rights and Restrictions:**

1. You may install for use one copy of the Software Product on a single machine;
2. You may make a copy of the Software Product for archive or backup purposes and the copy is to be used on this machine only;
3. You may transfer the Software Product and the license agreement to a third party, provided that the third party accepts the terms and conditions stated in this agreement, with prior express permission from Weihong Company;
4. When transfer confirmed, you shall transfer all the copies of the original documents and the supplementary documents to the third party or destroy all the copies un-transferred.
5. You can use the Software Product on a network server or intranet server only if it is stipulated in explicit terms that you are allowed to use the Software Product on a network server or intranet server, or you have purchased license for each node and terminal using the Software Product;
6. You may NOT sublicense, assign or transfer the license agreement;
7. You may NOT or direct any third party to reverse engineer, decompile or disassemble the Software Product;
8. You may NOT copy or transfer the Software Product or any part of the Software Product unless otherwise expressly stated in this agreement;
9. The license agreement shall be terminated automatically upon you transfer the Software Product or copies of all or part of the Software Product to a third party.

**Intellectual Property Rights Notice:**

The Software Product and all intellectual property rights therein (including but not limited to any all copyrights, patents, trademarks, and publicity rights) are owned by Weihong Company. The Software Product is protected for Weihong Company on the basis of copyright law and international treaty provisions as well as on the basis of other laws and agreements regarding intellectual property. You are not allowed to remove the copyright statement made in the Software Product, and guarantee that you shall copy the copyright statement in all copies of the Software Product or of any part of the Software



Product. You are obliged to stop any form of illegal copying of the Software Product and accompanying materials.

**After-sales Guarantee:**

Weihong Company guarantees that for 90 days from the date of shipment the software carrier will be free from defects in materials and workmanship. When such a defect has been confirmed, our only responsibility is to replace the software carrier. This remedy is your exclusive remedy. This after-sales guarantee is invalid for any carrier defect caused by accidents, abuses or maloperation. The replaced software carrier enjoys the remaining guarantee time of the original software carrier or of a 30-day guarantee time, whichever is longer.

Except as the after-sales guarantee made above, the Software Product does not enjoy any other form of after-sale guarantee.

**Limitation of Liability:**

The above guarantee, whether made explicitly or by implication, constitutes the entire contents of the guarantee, including guarantee for the commerciality and applicability of special application aim. Whether you follow other terms in this agreement or not, Weihong Company, as well as its agents and sales staff, will not be responsible for any profits loss, availability loss, business break-off or any forms of indirect, special, accidental or inevitable damage or claim made by any third party, generated from the using of the Software Product, even if Weihong Company has been informed of the possible occurrence of such events in advance.

**Termination:**

This license may be terminated by Weihong Company at any time once you violate any terms or conditions made in this agreement. Once the license is terminated, you are obliged to destroy all the copies of the Software Product or return them to Weihong Company.

**Applicable Law:**

*Copyright Law, Regulations for the Protection of Computer Software, Patent Law* and other relevant laws and regulations.

Now, we affirm that you have already read through this agreement and understood it thoroughly and agreed to comply with all of the terms and conditions of this agreement strictly.

Weihong Electronic Technology Co., Ltd.